




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6G453701	Drag Knob	41	6G193601	Bearing Retainer
2	6F373301	Drag Washer Retainer	42	6G426301	Ball Bearing (B)
3	6E467201	Key Washer	43	6G193501	Collar (B)
4	6E136001	Drag Washer	44	6B275403	Washer (C)
2-5	6G453502	Spool Assembly	45	6F622301	Clutch Cam Retainer
6	6E467101	Washer (A)	46	6F622201	Clutch Cam
7	6F704901	Spool Click Leaf Spring	47	63758502	Washer (D)
8	6E122308	Click Leaf Spring Holder	48	6F732501	Spacing Sleeve
9	6F811501	Click Gear	49	6G220601	Roller Clutch
12	6G291401	Main Shaft	50	6G285801	Ball Bearing (C)
13	6G061601	Oscillating Slider	51	63758504	Washer (E)
14	63510315	Screw (A)	52	6G291101	Pinion Gear
15	6F336102	Rotor Nut	53	6G453302	Body
16	6G206214	Rotor	54	6G193108	Anti-Reverse Lever
17	6G195601	Screw (B)	55	6G193301	Anti-Reverse Cam Spring
18	6G206406	Bail Arm	56	6G114300	Washer (F)
19	6G224901	Screw (C)	57	6F691702	Oscillating Gear
21	6F897101	Washer (B)	58	6G206105	Rear Cover
22	6G285701	Ball Bearing (A)	59	6G400102	Screw (H)
23	6F921601	Line Roller	60	6G061701	Drive Gear
24	6G047601	Collar (A)	61	63758500	Washer (G)
25	6G206601	Bail Assembly	62	6G285801	Ball Bearing (D)
26	63516101	Screw (D)	63	6G206009	Side Cover
27	6G017503	Bail Spring Shaft	64	6G332902	Screw (I)
28	6G062401	Bail Spring	65	6G333002	Screw (J)
29	6G017401	Bail Spring Holder	66	6G453401	Handle Assembly
30	6G206506	Cover (A)	67	6F721001	Collar (C)
31	6G205102	Screw (E)	68	6F676510	Handle Screw
32	6G195101	Bail Holder Nut	69	63753005	Washer (H)
33	6G450101	Cover (B)	71	6G256401	Washer (I)
34	6G194101	Bail Trip Lever Spring	72	6G256401	Washer (J)
35	6G265701	Bail Trip Lever			
37	6G194301	Brake Shoe			
39	6G193701	Screw (F)			
40	6G332701	Screw (G)			

THEORY 2000 SPECIAL PARTS

Key No.	Parts No.	Parts Name
2-5	6G453802	Spool Assembly