




Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6G454901	Drag Knob	39	6G193701	Screw (F)
2	6F373301	Drag Washer Retainer	40	6G332701	Screw (G)
3	6F094901	Key Washer	41	6G353701	Bearing Retainer
4	63733603	Eared Washer	42	6G353401	Ball Bearing (B)
5	6E136001	Drag Washer	43	6G353601	Collar (B)
2-9	6G454702	Spool Assembly	45	6F641501	Clutch Cam Retainer
7	6B075304	Click Pawl	46	6F641401	Clutch Cam
8	6G366501	Click Spring	47	6G353501	Spacing Sleeve
9	63205901	Click Retainer	48	6G314501	Roller Clutch
10	6F094701	Washer (A)	49	6G353401	Ball Bearing (C)
11	6E462701	Click Gear	50	63737814	Washer (D)
12	6G291601	Main Shaft	52	6G291301	Pinion Gear
13	6G025501	Oscillating Slider	53	6G454502	Body
14	63521505	Screw (A)	54	6G193109	Anti-Reverse Lever
15	6G123301	Rotor Nut	55	6G193301	Anti-Reverse Cam Spring
16	6G230214	Rotor	56	6G131700	Washer (E)
17	6G195601	Screw (B)	57	6F747801	Oscillating Gear
18	6G194507	Bail Arm	58	6G230105	Rear Cover
19	6G224901	Screw (C)	59	6G400102	Screw (H)
21	6F897101	Washer (B)	60	6G025601	Drive Gear
22	6G285701	Ball Bearing (A)	61	63737800	Washer (F)
23	6F921601	Line Roller	62	66316901	Ball Bearing (D)
24	6G047601	Collar (A)	63	6G230010	Side Cover
25	6G230401	Bail Assembly	64	6G332902	Screw (I)
26	63516101	Screw (D)	65	6G333002	Screw (J)
27	6G017502	Bail Spring Shaft	66	6G454601	Handle Assembly
28	6G148601	Bail Spring	67	6F721201	Collar (C)
29	6G017401	Bail Spring Holder	68	6F425806	Handle Screw
30	6G230306	Cover (A)	69	6F131601	Collar (D)
31	6G205102	Screw (E)	70	6G256401	Washer (G)
32	6G195101	Bail Holder Nut	72	6G256401	Washer (H)
33	6G450301	Cover (B)			
34	6G194101	Bail Trip Lever Spring			
35	6G265402	Bail Trip Lever			
37	6G194301	Brake Shoe			
38	63753002	Washer (C)			

THEORY 4000 SPECIAL PARTS

Key No.	Parts No.	Parts Name
2-9	6G455002	Spool Assembly