

PARTS DIAGRAM & PARTS LIST


ENGINE MOUNT

24 VOLT

The parts diagram and parts list provides Minn Kota® WEEE compliance disassembly instructions. For more information about where you should dispose of your waste equipment for recycling and recovery and/or your European Union member state requirements, please contact your dealer or distributor from which your product was purchased. Tools required, but not limited to: flat head screwdriver, Phillips screwdriver, socket set, pliers, wire cutters.

ENGINE MOUNT MOTOR

Engine Mount Parts Diagram



Engine Mount Parts List

Assembly	Part #	Description	Quantity
A	2994856	BAG ASSY, EM	1
C	2990239	HAND CONTROLLER ASSY, EM	1
D	2396233	MTR ASY 24V 4" 80#	1
E	1378132	PROP KIT PWR PRP	1
F	2990247	CTRL MOD ASY 24/36V, SINGLE	1
G	2889460	SEAL & O-RING KIT *4.0*	1
Item	Part #	Description	Quantity
2	2-100-234	ARM ASY 24V 4IN. 80#	1
4	140-010	BEARING - BALL	1
6	2-200-161	CTR HSG ASY 4.0	1
8	421-276	PLAIN END HSG 4" FW EM	1
10	2-300-149	BRSH END HSG 4" FW EM	1
12	144-017	BEARING - FLANGE	1
14	725-095	PAPER TUBE - SEAL BORE	1
16	880-025	SEAL	2
18	973-025	SPACER-BRUSHPLATE	2
20	2-600-234	BRUSH PLATE ASSEMBLY- 4" EM	1
22	188-094	BRUSH ASSEMBLY	2
24	640-234	LEADWIRE ASSEMBLY 10 AWG	1
28	975-041	SPRING - TORSION	2
32	701-009	O-RING	2
34	701-043	O-RING	2
36	830-027	SCREW, SELF-THREAD	2
38	830-094	THRU BOLT 12-24 X 10.31	2
40	990-051	WASHER - STEEL THRUST	1
42	990-052	WASHER - NYLATRON	2
44	836-001	PLUG ALUMINUM 1/8 X 27 NPT	1
46	2331160	PROP-PWR (3 5/8") REAMED	1
48	2091701	WASHER-5/16 STD (S/S)	1
50	2262658	PIN-DRIVE 1.06" LG (SS)	1
52	2093101	NUT-PROP,NYLOC 3/8 SS	1
54	992-010	WASHER BELLEVILLE	2
56	990-045	SPACER-THRUST	1
58	2381940	BRACKET, LOWER MOUNT	1
60	2383810	STRAP, EM	1
62	2380215	CAP-TOP (EM) FW	1

✱ This part is included in an assembly and cannot be ordered individually.

▲ Not shown on Parts Diagram.

////////////////////////////////////

▲ Not shown on Parts Diagram.