




109-LH LEFT HAND



Penn Reel Parts list for:

KEY PART

NO NO.

DESCRIPTION

1 1-109LH	LEFT SIDE PLATE (LEFT HAND VERSION)
2 2-109	LEFT SIDE RING
3 3-109LH	BRIDGE W/ SLEEVE (LEFT HAND VERSION)
4 4-155	FIBER WASHER
5 5-109LH	MAIN GEAR (LEFT HAND VERSION)
6 6-155	DRAG WASHER-HT 100
7 7C-155	WASHER (METAL SET)
8 8-60	TENSION SPRING
9 9-60	SPACING SLEEVE
10 10-180LH	STAR DRAG (LEFT HAND VERSION)
13 13-109LH	PINION GEAR (LEFT HAND VERSION)
14 14-109	DOG SPRING
15 15-109	DOG
16 16-60	LOWER BRIDGE SCREW (2 REQ.)
17 17-60	UPPER BRIDGE SCREW (2 REQ.)
19 19-109LH	ECCENTRIC (LEFT HAND VERSION)
20 20-109	ECCENTRIC SPRING
21 21-109	ECCENTRIC LEVER
22 22-109	ECCENTRIC SCREW
23 23-180	HANDLE SCREW
23A 23-180	HANDLE LOCKING SCREW
24 24-109	HANDLE
26 26-109	LEFT SIDE BEARING

Model: 109M-LH LEFT Hand Version

KEY PART

NO NO.

DESCRIPTION

27 27-109LH	RIGHT SIDE PLATE (LEFT HAND VERSION)
28 28-109	RIGHT SIDE RING
29L 29L-109	SPOOL (ALUMINUM)
30 30N-9	STAND
32 32-2	STAND SCREW (4 REQ.)
35 35-155	CLICK TOUNGE
36 36-109	CLICK BUTTON
37 37-109	FRAME POST (2 REQ.)
39 39-1	L.S. POST SCREW (6 REQ.)
40 40-109	L.S. BEARING
41 41-109	L.S. BEARING SPRING
42 42-109	WORM
43 43-109	LEFT SIDE WORM BEARING
44 44N-109	RIGHTSIDE PLATE (LEFT HAND VERSION)
44A 57-109	WORM BEARING SPRING
45 45-109LH	WORM GEAR (LEFT HAND VERSION)
46 46-109LH	LINE GUIDE (LEFT HAND VERSION)
47 47-109	PAWL
48 48-109	PAWL COVER
50 50-109	WORM SHIELD
58 58-109	SLOTTED POST
98 98-155LH	GEAR SLEEVE (LEFT HAND VERSION)