




49L-LH Super Mariner Left Hand Version

Penn Reel Parts list for:

Model: 49L-LH Super Mariner (LEFT Hand Version)

KEY PART NO.	NO.	DESCRIPTION	KEY PART NO.	NO.	DESCRIPTION
1	1-49LH	LEFT SIDE PLATE (LEFT HAND VERSION)	22	22-60CH	ECCENTRIC SCREW (2 REQ.)
2	2-49-OL	OUTER RING	23	23-60	HANDLE SCREW
2A	2-49-I	INNER RING	23A	110-60	HANDLE LOCK SCREW
3	3-49LH	BRIDGE W/ SLEEVE (LEFT HAND VERSION)	24	24-49	HANDLE
4	4-60	FIBER WASHER	26	26-60	LEFT SIDE BEARING
5	5-49LH	MAIN GEAR (LEFT HAND VERSION)	27	27-49	RIGHT SIDE PLATE
6	6-49	DRAG WASHER (3 REQ.)	28	28-49-O	OUTER RIGHT SIDE RING
7	7C-49	METAL WASHER SET	28A	2-49-I	INNER RING
8	8-60	TENSION SPRING	29L	29L-49	SPOOL
9	9-60	SPACING SLEEVE	30	30-49	STAND
10	10-49LH	STAR DRAG WHEEL (LEFT HAND VERSION)	31	39-3	RIGHT/RIGHTSTAND SCREW
11	11-49	ECCENTRIC JACK	33	33-49	ROD CLAMP
12	12-60	PINION YOKE	34	34-49	ROD CLAMP SCREWS (2 REQ.)
13	13-49LH	PINION (LEFT HAND VERSION)	34C	34C-49	ROD CLAMP SCREW W/ NUTS
14	14-60	DOG SPRING	35	35-60	CLICK TONGUE
15	15-49LH	DOG (LEFT HAND VERSION)	36	36-60CH	CLICK BUTTON
16	16-60CH	LOWER BRIDGE SCREW (2 REQ.)	37	37-49	POST (6 REQ.)
17	17-60CH	UPPER BRIDGE SCREW (2 REQ.)	38	39-9	RIGHT/LEFT SIDE POST SCREW (6 REQ. PER SIDE)
18	18-60	CLUTCH SPRING (2 REQ.)	40	40-60	RIGHT SIDE BEARING
19	19-60	ECCENTRIC CAM	41	41-60	RIGHT SIDE BEARING SPRING
19A	19-49	ECCENTRIC CAM	62	62-309	CLICK SPRING
20	20-60LH	ECCENTRIC SPRING (LEFT HAND VERSION)	62A	63-209	CLICK SPRING SCREW
20A	20-155	ECCENTRIC SPRING	98	98-60LH	GEAR SLEEVE (LEFT HAND VERSION)
21	21-49	ECCENTRIC LEVER	149	149-200	HEX NUT
			152	152-200	WING NUT