


Congratulations on the purchase of your new
Penn International® baitcaster! For general
features, operating instructions, casting control
information, maintenance, lubrication and
servicing, please refer to the main International®
manual (featuring the 965). Keep this sheet
for reference to 975LD part numbers and
specifications. Good fishing!



LINE CAPACITY	GEAR RATIO	WEIGHT
300 YDS / 15 LBS 275 METERS / 0.40 MM	4.4-1	17 OZ 480 GRAMS

**KEY
NO.**

DESCRIPTION	PART NO.
Rod Clamp Screw (2 req.)	034 975
Click Tongue	035 965
Click Button	036 975
Click Housing	036B975
Click Wheel	036C965
Click Wheel Spring	036D965
Click Tongue Pin	036E965
Retaining Ring	036R965
Thumb Bar Post	037 975
Thumb Bar	037A975
Take-Apart Screw (2 req.)	038 975LD
Side Plate Washer (3 req.)	038BN965
Screw 'O' Ring (3 req.)	038CN965
Take-Apart Screw	038N965
L.S. Plate Screw (2 req.)	039 965
L.S. Plate Short Screw	039S965
Metal Thrust Washer	040C310
Bearing Spring	041 975LD
Worm Shaft	042 975
Metal Washer	042R965
L.S. Worm Shaft Washer	042L965
R.S. Worm Shaft Washer	042R965
R.S. Worm Shaft Bushing	043 965
Worm Bushing Screw	043B965
L.S. Worm Shaft Bushing	044 975
Line Guide	046 975
Pawl	047 975
Pawl Cover Screw	048 965
Worm Shield	050 975
Pre-Set Knob Screw	050 716
Ball Bearing	055 965
Gear Stud Bushing	055A965
Spool Bearing	055 116
Spool Bearing	055 113H
Left Side Bearing	055 113H
Line Guide Post	058 975
Eccentric Washer	060 975LD
Brake Drum	061 965
Brake Drum Screw (2 req.)	043B965
Click Spring (2 req.)	062A965
Idler Gear	064 975
Idler Gear Pin	065 965
Idler Gear Washer	065W965
Spool Gear Click Ratchet	066M965
Lock Ring	067 016S
Retaining Ring	069B050
Spool Retaining Ring	069 975LD
Retaining Ring (2 req.)	069B600
Spool Spindle	071R975LD
Clutch Bearing	098B525
Bearing Clutch Sleeve	098S525
Retaining Plate Screw (3 req.)	101 050S
Handle Nut Cap	110A555
Drive Plate Assembly	117 975LD
Retaining Plate	119 030S
Eccentric O-Ring	026R965
Gear Stud	134 975LD
Cam Follower (2 req.)	142 975LD
Preset Knob	144 975LD
Preset Knob Cap	144C975LD
Preset Knob Click Ball	144D975LD
Rod Clamp Nut (2 req.)	149 045
Drag Cover	156 975LD
Strike Button	161 975LD
L.S. Bearing Retainer	173 965
Anti-Backlash Brakes (4 req.)	176 975LD
Brake Selection Knob	177 965
Frame Assembly	183N975LD

**KEY
NO.**

DESCRIPTION	PART NO.
Right Side Plate	001 975LD
Quadrant Ring	002 975LD
Quadrant Bushing	002B975LD
Inner R.S. Plate	003 975LD
Main Gear	005 975LD
Drag Washer HT-100	006 975LD
Handle Collar	009 975LD
Bridge Screws (3 req.)	016 975LD
Long Bridge Screw	017 975LD
Disc Clutch Spring (4 req.)	018 975LD
Cam Assembly	019 975LD
Eccentric Lever	021 975LD
Post Screw (2 req.)	050 716
Handle Nut	023 555
Handle Assembly	024 555
R.S. Plate Bearing	026N025
Left Side Plate	027 975
Spool Assembly	029L975LD
Handle Cap Screw	032 015
Quadrant Screw	032 975LD
Rod Clamp	033 113

**PART
NO.**

DESCRIPTION	PART NO.
Right Side Plate	001 975LD
Quadrant Ring	002 975LD
Quadrant Bushing	002B975LD
Inner R.S. Plate	003 975LD
Main Gear	005 975LD
Drag Washer HT-100	006 975LD
Handle Collar	009 975LD
Bridge Screws (3 req.)	016 975LD
Long Bridge Screw	017 975LD
Disc Clutch Spring (4 req.)	018 975LD
Cam Assembly	019 975LD
Eccentric Lever	021 975LD
Post Screw (2 req.)	050 716
Handle Nut	023 555
Handle Assembly	024 555
R.S. Plate Bearing	026N025
Left Side Plate	027 975
Spool Assembly	029L975LD
Handle Cap Screw	032 015
Quadrant Screw	032 975LD
Rod Clamp	033 113