




3/0 Senator 112H



Penn Reel Parts list for:

KEY NO	PART NO.	DESCRIPTION
	1 1-112H	RIGHT SIDE PLATE
	2 2-112H-O	OUTER RIGHT SIDE RING
	2A 2-112H-I	INNER RING (2 REQ.)
	3 3-112H	BRIDGE W/ SLEEVE
	4 4-60	FIBER WASHER
	5 5-500	MAIN GEAR
	6 6-309	DRAG WASHER (3 REQ.)
	7 7C-500	METAL DRAG WASHER SET (3 REQ.)
	8 8-60	TENSION SPRING
	9 9-60	SPACING SLEEVE
	10 10-60	STAR DRAG WHEEL
	11 11-99	ECCENTRIC JACK
	12 12-500	PINION YOKE
	13 13-500	PINION
	14 14-99	DOG SPRING
	15 15-309	DOG
	16 16-60CH	LOWER BRIDGE SCREW (2 REQ.)
	17 17-60CH	UPPER BRIDGE SCREW (2 REQ.)
	18 18-60	CLUTCH SPRING (2 REQ.)
	19 19-250	ECCENTRIC
	20 20-60L	ECCENTRIC SPRING
	21 21-49	ECCENTRIC LEVER
	22 22-99	ECCENTRIC SCREW
	23 23-60	HANDLE SCREW
	23A 110-60	HANDLE LOCK SCREW

Model: 112H

KEY NO	PART NO.	DESCRIPTION
	24 24-112H	HANDLE
	26 26-155	R.S. BEARING
	27 27-112H	LEFT SIDE PLATE
	28 28-112H-O	OUTER LEFT SIDE RING
	29 29L-112H	SPOOL
	30 30-66	STAND
	31 39-3	R.S. STAND SCREW (2 REQ.)
	32 32-17	L.S. STAND SCREW (2 REQ.)
	33 33-113	ROD CLAMP
	* 33R-200	RINGED ROD CLAMP (OPTIONAL)
	34 34-45	CLAMP SCREW (2 REQ.)
	34C 34C-45	ROD CLAMP SCREW W/ NUTS
	35 35-60	CLICK TOUNGE
	36 36N-209	CLICK BUTTON
	37 37-65	FRAME POST (5 REQ.)
	38 39-9	R.S. SCREW (5 REQ.)
	39 39-3	L.S. SCREW (5 REQ.)
	40 40-60	L.S. BEARING
	41 41-60	L.S. BEARING SPRING
	62 62-309	CLICK SPRING
	62A 63-209	CLICK SPRING SCREW
	69 69B-600	RETAINING RING
	98 98-60	GEAR SLEEVE
	149 149-45	ROD CLAMP NUT (2 REQ.)
	149A 149-200	HEX NUT (2 REQ.)

* Not Shown