





4/0 SENATOR 113-LH Left Hand Version



Penn Reel Parts list for:

Model: 113-LH Senator (LEFT HAND Version)

KEY NO	PART NO.	DESCRIPTION	KEY NO	PART NO.	DESCRIPTION
1	1-113	LEFT SIDE PLATE	24	24-66	HANDLE
2	2-113-O	OUTER RING (2 REQ.)	26	26-60	R.S. BEARING
2A	2-113-I	INNER RING (2 REQ.)	27	27-113	RIGHT SIDE PLATE
3	3-113LH	BRIDGE W/ SLEEVE (LEFT HAND VERSION)	29	29L-113	SPOOL
4	4-60	FIBER WASHER	30	30-113	STAND
5	5-66LH	MAIN GEAR (LEFT HAND VERSION)	31	32-17	R.S. STAND SCREW
6	6-113	DRAG WASHER (3 REQ.)	32	39-9	L.S. STAND SCREW (3 REQ.)
7	7C-60	METAL DRAG WASHER SET	33	33-113	ROD CLAMP
8	8-60	TENSION SPRING (2 REQ.)		* 33R-200	RINGED ROD CLAMP (OPTIONAL)
9	9-66	SPACING SLEEVES	34	34-45	CLAMP SCREW (2 REQ.)
10	10-66LH	STAR DRAG WHEEL (LEFT HAND VERSION)	34C	34C-45	ROD CLAMP SCREW W/ NUTS
11	11-113	ECCENTRIC JACK	35	35-60	CLICK TONGUE
12	12-113	PINION YOKE	36	36-113	CLICK BUTTON
13	13-113LH	PINION (LEFT HAND VERSION)	37	37-113	FRAME POST (5 REQ.)
14	14-99	DOG SPRING	38	39-9	R.S. SCREW (5 REQ.)
15	15-99	DOG	39	39-9	L.S. SCREW (5 REQ.)
16	16-60CH	LOWER BRIDGE SCREW (2 REQ.)	40	40-60	L.S. BEARING
17	17-60CH	UPPER BRIDGE SCREW (2 REQ.)	41	41-60	L.S. BEARING SPRING
18	18-60	CLUTCH SPRING (2 REQ.)	54	54-113	HARNES LUG (2 REQ.)
19	19-113	ECCENTRIC	62	62-309	CLICK SPRING
20	20-155	ECCENTRIC SPRING	62A	63-209	CLICK SPRING SCREW
21	21-66	ECCENTRIC LEVER	69	69B-600	RETAINING RING
22	22-99	ECCENTRIC SCREW	98	98-60LH	GEAR SLEEVE (LEFT HAND VERSION)
23	23-60	HANDLE SCREW	149	149-45	ROD CLAMP NUT (2 REQ.)
23A	110-60	HANDLE LOCK SCREW	149	149-200	HEX NUT (2 REQ.)

* Not Shown