




PARTS LIST FOR MODEL BTLII8000LCLL-USA/BTLII8000LCLL-EU



KEY NO.	PART NO.	DESCRIPTION
43	1347207	43-BTLII8000LCLL Worm O/S Slider
43A	1347173	43A-BTLII8000LCLL Slider Retainer Plate
43B	1277054	28S-SSV5500 O/S Slider Retainer Screw (2req.)
43D	1132097	43D-BTLII8000LCLL Guide Claw Bushing
43E	1122192	43E-7000AF Guide Claw
43F	1378432	43F-BTLII8000LCLL Guide Shaft
43G	1378433	43G-BTLII8000LCLL Worm Shaft
43H	1377609	43H-BTLII8000LC Worm Shaft Ball Bearing
43J	1347204	43J-BTLII8000LCLL Top Retainer Plate
43L	1341533	43L-SSV7500LC Worm Shaft Bushing
43M	1347170	43M-BTLII8000LCLL Worm Shaft Rear Bushing
43N	1347174	43N-BTLII8000LCLL W/Shaft Retainer Plate Screw(2req.)
43R	1347175	43R-BTLII8000LCLL Worm Shaft Retainer Plate
45	1378434	45-BTLII8000LCLL-USA Body Cover Assembly
45	1378435	45-BTLII8000LCLL-EU Body Cover Assembly
46	1377611	46-BTLII8000LC Body Cover Screw(4req.)
46A	1131811	46A-BTLII8000LCLL Body Cover Screw(2req.)
47	1378436	47-BTLII8000LCLL Spool Assembly
47B	1341538	47B-SSV7500LC-USA Spool Band
47C	1377615	47C-BTLII8000LC Drag Cover
47E	1378437	47E-BTLII8000LCLL Line Clip Bushing
47F	1259575	47F-7000AF Line Clip Spring
47P	1378438	47P-BTLII8000LCLL Spool
47S	1377618	47S-BTLII8000LC Drag Cover Seal
47T	1377619	47T-BTLII8000LC Drag Cover Screw(4req.)
48	1259577	13-7000AF Spool Click Plate
48D	1341546	48D-SSV7500LC Spool Clicker Spacer Ring
49	1259579	49-7000AF Spool Click Spring
49A	1341547	49A-SSV7500LC Spool Clicker Spring Screw(2req.)
52	1377620	52-BTLII8000LC-USA Drag Knob Assembly
52	1377621	52-BTLII8000LC-EU Drag Knob Assembly
53S	1377622	53S-BTLII8000LC Drag Knob Seal
56	1377623	56-BTLII8000LC Drag Friction Washer(2req.)
57	1122159	57-AF8000LC Top Keyed Drag Washer
57T	1122162	57T-AF8000LC Keyed Drag Washer
70	1378439	70-BTLII8000LCLL R- Drag Switch Lever-L
70A	1378440	70A-BTLII8000LCLL R- Drag Switch Lever-R
70B	1117351	70B-BTLII8000LCLL R- Drag Switch Lever Screw
70C	1277128	70B-SSV5500LC R- Drag Switch Lever Screw
71	1131817	71-BTLII8000LCLL Live Liner Lever Spring
72	1378441	72-BTLII8000LCLL Rear Drag Switch Cam
74	1347180	74-BTLII8000LCLL Live Liner Trip lever(A)
74A	1378442	74A-BTLII8000LCLL Rear Trip Lever-B
74B	1347179	74B-BTLII8000LCLL Live Liner Trip lever Spring
74C	1131794	74C-BTLII8000LCLL Live Liner Trip lever Bushing
74D	1117948	74D-BTLII8000LCLL Stop Claw Spring Washer
74E	1277230	74E-SSV8500LC Live Liner Three Pawl Lever
74F	1277231	74F-SSV8500LC Live Liner Three Pawl Lever Spring
74G	1277232	74G-SSV8500LC Live Liner Three Pawl Lever E-Clip
76	1131819	76-BTLII8000LCLL Live Liner Claw Spring
77	1378443	77-BTLII8000LCLL Live Liner Stop Claw
77B	1131780	77B-BTLII8000LCLL Live Liner Trip Lever Screw
82	1378444	82-BTLII8000LCLL Rear Drag Housing
83	1378445	83-BTLII8000LCLL Rear Drag Ratchet
83A	1347186	83A-BTLII8000LCLL Rear Drag Ratchet Washer
83B	1131822	83B-BTLII8000LCLL Rear Drag Ratchet Retainer
84	1347183	84-BTLII8000LCLL Rear Drag Clicker
84A	1347184	84A-BTLII8000LCLL Rear Drag Clicker Shaft
84B	1380083	84B-BTLII8000LCLL Rear Drag Clicker Gear
85	1131823	85-BTLII8000LCLL Rear Drag Washer(4req.)
85A	1131826	85A-BTLII8000LCLL Rear Drag Keyed Washer
85B	1131825	85B-BTLII8000LCLL Rear Drag Eared Washer
85C	1131827	85C-BTLII8000LCLL Rear Drag Washer
86	1131828	86-BTLII8000LCLL Rear Drag Spring
86A	1347187	86A-BTLII8000LCLL Rear Drag Bushing
87	1347249	87-BTLII8000LCLL Rear Drag Knob Pin
87A	1347248	87A-BTLII8000LCLL Rear Drag Knob Clicker Spring
88	1378446	88-BTLII8000LCLL Rear Drag Knob
88C	1378447	88C-BTLII8000LCLL Rear Drag Knob Screw
88D	1132105	88D-BTLII8000LCLL Rear Drag Knob Retainer
95B	1277189	95B-SSV7500 Rotor Nut Locking Plate
98	1378448	98-BTLII8000LCLL O/W Clutch Assembly
98A	1378449	98A-BTLII8000LCLL Clutch Assembly Spring
132	1277192	132-SSV7500 Line Roller Collar
132A	1277097	132A-SSV5500 Line Roller Washer
231	1347205	231-BTLII8000LCLL O/S Gear
231E	1378450	231E-BTLII8000LCLL Slow O/S Gear
231F	1347163	231F-BTLII8000LCLL Slow O/S Gear Pin
231G	1347162	231G-BTLII8000LCLL O/S Gear Pin Screw(2req.)
233A	1377626	233A-BTLII8000LC Handle Cap