


CURADO

CU-70HG



(51RH391070U)

#	Part No.	Description	#	Part No.	Description	#	Part No.	Description
623	103C0	Screw	4884	10F3X	Clutch Cam Retainer	5333	10LFX	Screw
686	105NK	E Lock	4885	10K0N	Clutch Cam	5334	10PXZ	Bushing
1652	10LVE	Screw	4886	10MME	Clutch Pawl	5335	10TPP	Worm Shaft
1672	105NC	E Lock	4922	10CMC	Drive Gear	5336	10R10	Level Wind Guard
1696	10896	Cast Control Spacer	4923	10CRW	Pinion Gear	5337	10R1H	Clutch Pawl Spring
1876	10LCV	Screw	4981	10LA8	O Ring	5338	10QZV	Clutch Plate
2123	10BT2	Click Spring	5264	10D73	Anti-Reverse Ratchet	5339	10R09	Clutch Guard
2127	10J1N	Star Drag Spacer	5275	10QSH	Stabilizer Bar	5341	10QZW	Clutch Bar Guide
2144	10C47	Washer	5277	10BGR	Cam Lever Retainer	5342	10R1J	Clutch Bar
2224	1085F	Spool Tension Spacer	5280	10B1X	Brake Dial	5343	1019B	Side Plate Cam Lever
3910	10F5D	Roller Clutch Bearing	5310	10HJG	Idle Gear Pin	5344	10MPD	Screw
3927	10EX8	Ball Bearing	5311	10LFC	Screw	5345	10DP2	Spool Assembly
4116	103E9	Screw	5312	10Q5T	Handle Nut Plate	5346	10EX5	Spacer B
4118	10HTT	Washer	5313	10DPC	Handle Assembly	5348	10L1Q	Screw
4124	10A70	Star Drag Spring	5314	10KXW	Click Plate Retainer	5349	10DLQ	Brake Case
4194	105BP	Ball Bearing	5315	10R3K	Star Drag Click Plate	5350	10GFC	Washer
4343	105C3	Ball Bearing	5316	10MFC	Click Pin	5351	10R3V	Br Dial Spacer
4588	10FJZ	Washer	5318	10QZZ	Cast Control Cap	5352	10R1S	Screw
4625	106XT	Drag Washer	5319	1054D	Bearing Retainer	5353	10ROU	Washer
4729	108WQ	O Ring	5320	10R22	O Ring	5354	10ROL	Left Side Plate
4860	10FFB	Handle Nut	5321	10DP9	Right Side Plate	5355	10R0K	Star Drag
4863	10A3T	Star Drag Nut	5322	10LCG	Screw	5383	10BHQ	Line Guide Pawl
4865	10EYS	Bearing Spacer	5323	10R05	Roller Clutch Inner Tube	5462	101Z6	Brake Ring Gear
4870	10CHF	Drag Washer	5324	10HJH	Key Washer Spacer	5609	10LCT	Screw
4872	10J47	Idle Gear	5325	10R0F	Key Washer	5629	10FMJ	Handle Knob Seal
4874	10FJB	Pawl Cap	5326	10R0A	Drive Shaft	5769	1025N	Handle Knob Assembly
4875	10NVQ	Line Guide	5327	10JDY	Idle Gear Spring	6807	10S2Z	Frame
4877	10FNV	Idle Gear	5328	10LCQ	Screw			
4878	10AEZ	Worm Shaft Pin	5329	109T1	Drive Shaft Retainer			
4882	10487	Yoke Spring	5330	10R12	Level Wind Protector			
4883	1046V	Yoke	5331	104TX	Spacer			

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(241029)_012