


SHIMANO

TIAGRA

TI-16



(51RJ200016U)

#	Part No.	Description	#	Part No.	Description	#	Part No.	Description
0002A	10QUC	Handle Bolt Plate	0583	102TX	Handle Assembly	0622	1089F	Pre-Program Key
0040A	1052C	Pre-Load Spring	0584	10PHS	Cover Screw	0623	1088Y	Pre-Program Screw
0042A	104L7	Bearing Thrust Washer	0585	108H6	Pre-Program Dial	0624	10N9K	Pinion Gear (B)
0069	105NK	E Lock	0586	10BHN	Lever Hub Cover	0625	10HYK	Pinion Shaft
0091	109XD	Push Button Shield	0587	10C3Q	Drag Control Button	0626	10MCU	Cross Pin (B)
0092	10LZ9	Handle Bolt Plate Screw	0588	10C3R	Drag Control Button Spring	0627	103L4	Alert Ratchet Screw
0093	10PWH	Slide Plate Spring	0589	108B2	Drag Control Lever	0628	105WX	Alert Ratchet
0094	109XC	Slide Plate	0590	10C3W	Lever Click Shoe	0629	10EML	Spool
0107	109VM	Drive Shaft Spring B	0591	10C3S	Lever Click	0630	10KJ6	Drag Plate Spring
0148	106XL	Handle Bolt	0592	105NC	E Lock	0631	10EVV	Pressure Plate (A)
0206	10D61	Friction Washer (C)	0593	10C3Y	Lever Click Cover	0632	10MT4	Drag Washer Screw
0209	10KXH	Gear Select Cross Bar	0594	10MGG	Lever Click Cover Screw	0633	10G13	Drag Washer
0211	10KXQ	Drive Shaft Spring	0595	10HWR	Lever Thrust Ring (A)	0634	10CCW	Pressure Plate Spring
0212	10D5B	Friction Washer (A)	0596	10PHR	Quadrant Anchor Bolt	0635	10G4A	Drag Plate
0213	10FCD	Drive Shaft Screw	0597	10C9S	Lever Quadrant	0636	104R6	Drag Plate Screw
0474	10KZQ	Drive Shaft Shield	0598	10CA6	Lever Quadrant Bushing	0637	10EZ6	Pressure Plate (B)
0475	107QW	Drive Shaft Thrust Washer	0599	10F3S	Right Side Plate (B)	0638	10EZ1	O Ring (A)
0478	10K06	Friction Shoe Spring	0600	103H3	Drive Shaft Holder Screw	0639	104QX	Cooling Shield
0479	1035W	Dial Click Shoe	0601	10PRP	Right Side Plate Screw	0640	10HX1	Cooling Shield Washer
0480	10J1W	Dial Click	0602	10F1T	Cross Pin Support Spring	0641	10LVJ	Cooling Shield Screw
0483	109RR	Dial Washer	0603	10EZT	Plunger Cross Pin (B)	0642	10KNU	Bearing Spacer
0484	105NG	E Lock	0604	10EZN	Plunger Cross Pin Support	0643	1059M	One-Piece Frame
0485	109RQ	Lever Thrust Ring (B)	0606	10CA9	Free Spool Detent	0644	107ZA	Left Side Plate
0512	104LD	Cross Pin (A)	0607	10BNP	Pressure Spring	0645	10PRR	Left Side Plate Screw
0524	10EW9	Waterproof Ring	0608	10CAG	Detent Bushing	0663	10HYQ	Bearing Spacer
0528	10PV9	Stand Screw	0609	103DH	Right Side Plate (B) Screw	0664	10MBJ	Harness Lug Screw
0529	10DAH	Anti-Reverse Ratchet	0610	103HE	Plunger Holder Screw	0665	10PYF	Harness Lug
0531	103E9	Set Plate Screw	0611	108CZ	Plunger Holder	0767	10BL5	Right Side Plate (A)
0532	10KVD	Set Plate	0612	10GV2	Plunger Spring	0873	10PHP	Screw
0533	10CBU	Dog Spring	0613	108D9	Alert Plunger	0874	10GFE	Washer
0534	10PKF	Dog	0615	10QK8	Drive Gear (A)			
0555	10PSY	Stand Washer	0616	109WU	Drive Gear (B)			
0556	10NV9	Stand	0617	10D5V	Drive Shaft			
0567	10JDE	Bearing Thrust Washer (B)	0618	10KXM	Cross Bar Stop	0646	10JBU	Rod Clamp Bolt (Accessory)
0570	104VH	Ball Bearing	0619	10HWV	Lever Shaft Body Washer	0647	10J9T	Rod Clamp (Accessory)
0575	10BMH	Ball Bearing	0620	10CC6	Lever Shaft Body	0648	10JC7	Rod Clamp Nut (A) (Accessory)
0582	109X8	Push Low Button Shaft	0621	10EWR	Pre-Program Key Pin	0649	10CXS	Rod Clamp Bolt (S) (Accessory)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(230301)_002