
# SHIMANO

## TYRNOS

## TYR-20II



(51RJ242020U)

| # | Part No. | Description | # | Part No. | Description | # | Part No. | Description |
|---|---|---|---|---|---|---|---|---|
| 20 | 1052C | Coned Disc Spring | 815 | 10LVG | Screw | 981 | 10M1U | Right Side Plate Cover |
| 42 | 105NE | E Lock | 818 | 10MGE | Screw | 983 | 10U0Y | Right Side Plate |
| 62 | 105NK | E Lock | 819 | 10G4B | Drag Plate | 984 | 10CBN | Dog Spring |
| 329 | 109RC | Spacer | 820 | 10EZ2 | O Ring | 986 | 10N0M | Guard Against Dog |
| 332 | 104B6 | Click Spring Retainer | 821 | 10G14 | Drag Washer | 987 | 10MKV | Screw |
| 334 | 104B8 | Click Spring Holder | 824 | 10ARP | Spool | 988 | 10PFX | Dog |
| 464 | 105RY | E Lock | 825 | 105S3 | C Lock | 989 | 109DL | Drive Gear A |
| 527 | 10D66 | Spacer | 826 | 104LB | Cross Pin | 990 | 10D61 | Friction Washer |
| 539 | 10QG5 | Screw | 827 | 104VH | Ball Bearing | 991 | 10LQG | Drive Gear B |
| 542 | 10K8T | Screw | 828 | 104L7 | Bearing Thrust Washer | 992 | 10999 | Drive Shaft |
| 546 | 10L9T | Screw | 829 | 10NZ7 | Click Gear | 993 | 10KXH | Gear Select Cross Bar |
| 560 | 10M6Z | Screw | 830 | 10PHQ | Screw | 994 | 10KXL | Cross Bar Stop |
| 591 | 104MU | Click Spring | 831 | 10HRX | Harness Lug Screw | 995 | 109VM | Drive Shaft Spring B |
| 639 | 10NRR | Click Pawl Spring | 832 | 10PYG | Harness Lug | 996 | 10KXQ | Drive Shaft Spring |
| 641 | 10K61 | Ball Bearing | 833 | 10K89 | One-Piece Frame | 997 | 10D5B | Friction Washer |
| 771 | 10549 | Click Pawl Spring Boss Ring | 834 | 10AR2 | Cross Bar | 998 | 10FCE | Drive Shaft Screw |
| 778 | 10M2Q | Screw | 835 | 10LES | Click Pawl | 999 | 10MFH | Right Side Seal |
| 779 | 10CCH | Screw Shield | 838 | 104TV | Spacer | 1000 | 10AHG | Pinion Gear A |
| 780 | 10LCA | Screw | 839 | 10505 | Left Side Plate | 1001 | 10U0W | Cooling Shield |
| 781 | 10C9T | Lever Quadrant | 840 | 10NX7 | Left Side Plate Cover | 1002 | 10HU8 | Pinion Gear B |
| 782 | 10HMF | Pre-Program Dial | 841 | 10NMY | Click Button Spacer | 1003 | 10ALM | Pinion Guard |
| 783 | 10M64 | Dial Spring | 968 | 10PHN | Screw | 1004 | 109LC | Pressure Release Spring |
| 784 | 108WL | O Ring | 969 | 109XD | Push Button Shield | 1005 | 10AEL | Spool Shaft |
| 785 | 10G4R | Washer | 970 | 10PWH | Slide Plate Spring | 1138 | 10ML4 | Screw |
| 786 | 10CC0 | Lever Shaft Body | 971 | 10LZ9 | Screw | 1178 | 1050M | Click Button |
| 788 | 10MFS | Lever Click Shoe | 972 | 109XC | Slide Plate | 1382 | 10G8Q | Anti-Reverse Pawl Spring Guide |
| 789 | 10MFR | Lever Click | 973 | 10QUC | Handle Bolt Plate | 2712 | 10SVL | Screw |
| 790 | 10MFT | Lever Click Cover | 974 | 10LS3 | Push Low Button Shaft | | | |
| 795 | 108DL | Lever Thrust Ring | 975 | 106XL | Handle Bolt | 351 | 10A7A | Rod Clamp Bolt (Accessory) |
| 796 | 10BND | Free Spool Detent | 976 | 10B1V | Handle | 352 | 105N9 | Rod Clamp Nut B (Accessory) |
| 797 | 10BNL | Pressure Spring | 977 | 107QU | Drive Shaft Shield | 353 | 10AR5 | Rod Clamp (Accessory) |
| 799 | 10BSP | Strike Stop | 978 | 10AMF | Washer | 354 | 1046P | Rod Clamp Nut A (Accessory) |
| 810 | 10BPJ | Drive Shaft Bushing | 979 | 10M5Y | Drag Control Lever | | | |
| 813 | 104JL | Ball Bearing | 980 | 10L1X | Screw | 1007 | 10MJ3 | Wrench (Accessory) |

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(230719)_003