


SHIMANO

EXSENCE

25EXSC30MHGB



(51SF942E38X)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

#	Part No.	RD No.	Description	#	Part No.	RD No.	Description	#	Part No.	RD No.	Description
1	149YU		Drag Knob Assembly	41	10DKC	18726	Bail Spring Guide A Bush	84	10R5Q	22059	Ball Bearing
2	14A1R		Spool Assembly	42	10SAN	19857	Bail Spring Guide A	85	10JAB	16480	O Ring
3	145QR	22803	Retainer	43	101D9	18724	Spring Guide A Support Collar	86	101D2	18760	Oscillating Guide B
4	10TJV	18710	Key Washer B	44	10R2P	17467	Bail Spring	87	13YJ8	22722	Idle Gear (Large)
5	10R5H	22029	Drag Washer A	45	10R2E	17468	Bail Spring Guide B	88	10R4Q	22061	Idle Gear C
6	102XW	15862	Eared Washer	46	13XDR	22521	Bail Trip Lever	89	100A7	22062	Main Shaft Assembly
7	10BBQ	15488	Key Washer A	47	10E8R	19708	Screw	90	106VL	16473	Oscillating Pawl
8	10R4W	22030	Drag Washer B	48	147HA		Bail Hold Support Guard	91	100CW	20436	Washer
9	10GEW	9912	Bearing Retainer	52	101D5	18732	Rotor Ring	92	108W9	9968	O Ring
10	104JT	13381	Ball Bearing	53	10DK7	18733	Friction Ring	93	101BY	18755	Oscillating Slider Bushing
11	10BQE	15489	Drag Click Spring	54	101D7	18734	Screw	94	10HAG	16470	Oscillating Pawl Cover
12	10TNV	17663	Drag Click	55	10S2L	18735	Roller Clutch Assembly	95	10R4V	22063	Screw
13	10A6F	14780	Screw	56	10DKD	18736	O Ring	96	10DKA	18747	Flange Water Proof
14	10DHG	19748	Spool Washer	57	10DJY	18737	Roller Clutch Inner	97	10R5U	22064	Ball Bearing
15	10DKF	18714	Spool Bearing Bushing	58	10ML6	16451	Screw	98	13XE7	22539	Drive Gear
16	10PN2	6008	Set Screw	59	10R53	22044	Bearing Retainer	99	1009S	22066	O Ring
17	104PP	13274	Ball Bearing	60	1022A	19008	Ball Bearing	100	1055G	15718	Screw
18	107V2	9833	Ratchet Spring	61	10RYR	18739	Washer	101	10EX8	17751	Ball Bearing
19	10SYS	18207	Drag Click Ratchet	62	10R5J	22077	Pinion Gear	102	1022D	22067	Washer
20	103PE	14867	Spool Support	63	10DJ1	19902	Washer	103	10R4Y	22068	Bail Trip Strike
21	10T1G	19139	Screw	64	10HV4	8216	Spacer	104	149YZ		Side Cover Assembly
22	1076N	19926	Nut Lock Plate	65	10R50	22046	Ball Bearing	105	10M2C	11568	Screw
23	10SPZ	22262	Bearing Water Proof	66	10R5T	22047	Idle Gear Spring	109	14A1T		Handle Assembly
24	10TD2	18715	Main Shaft Spacer Assembly	67	10R5K	22048	Idle Gear Shaft	110	10PXU	16465	Handle Shaft Seal
25	13YVU		Washer	68	13XDV	22525	Idle Gear C Shaft	111	10TJW	18749	Handle Shaft Cover B
26	10R5F	22033	Rotor Nut	69	108WA	9903	O Ring	112	10FJ6	8165	Handle Washer
27	148G0		Rotor Rim	70	100AB	21680	Handle Screw Cap	113	149Z1		Handle Shank Assembly
28	149YW		Rotor Assembly	71	14A1S		Body Assembly	114	104VX	13269	Ball Bearing
29	10CGZ	9931	Click Spring	72	10R4U	22052	Oscillating Guide A	115	10RHC	20709	Handle Knob
30	106UX	8759	Click Pin	73	10R55	22053	Worm Shaft	116	104FH	19745	Washer
31	10R52	22037	Bail Arm Fin	74	10TH6	19114	Bushing	117	103E9	2110	Screw
32	148G2		Bail Arm	75	100XZ	19744	Washer	118	13YZA		Handle Knob Seal
33	13XDP	22519	Washer	76	10TK0	18758	Washer				
34	10RFW	19421	Screw	77	10R5G	22054	Worm Shaft Retainer				
35	10TLJ	18210	Screw	78	103EB	16478	Screw				
36	1020L	18160	Bearing Spacer	79	10R5V	22055	Rear Protector				
37	101KE	18161	Line Roller Set	80	106ZG	9849	Screw				
38	149YX		Bail Assembly	81	10092	22056	O Ring				
39	1002S	19224	Washer	82	10R5N	22057	Idle Gear Spring				
40	10EAP	18452	Line Roller Support	83	10R5L	22058	Idle Gear	501	10TD4	22073	Bail Arm Fin (accessory)