


SHIMANO

STELLA SW

STLSW8000HGD



(51SF849P83X)

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

#	Part No.	RD No.	Description	#	Part No.	RD No.	Description	#	Part No.	RD No.	Description
1	14A3H		Drag Knob Assembly	54	146WZ		Rotor Guard B	106	10TK0	18758	Washer
3	1077S	9501	Click Spring	55	1016P	19557	Line Roller Plate	107	1015D	19586	Bushing
4	10361	8076	Drag Click	56	1016K	19562	Line Roller Seal	108	101NF	16996	O Ring
5	14A8Z		Spool Assembly	57	104W1	7915	Ball Bearing	109	147FU		Worm Shaft Retainer
6	146WS		Spool Ring Collar	58	1015Z	19561	Bushing	110	103EB	16478	Screw
7	10DU5	19538	O Ring	59	1015L	19541	O Ring	111	146WF		Rear Protector
8	146WR		Spool Ring	60	1014P	19571	Bearing Spacer	112	10L9D	8059	Screw
9	10B6F	7979	Retainer	61	10DUT	19553	Line Roller	113	14A3N		Main Shaft Assembly
11	146WT		Thrust Bushing	62	1014N	19559	Collar	114	106V5	12459	Oscillating Pawl
12	10KX7	12482	Ball Bearing	63	14A90		Bail Assembly	115	14813		Washer
13	1015Z	19546	Bearing Support	64	10Q3F	15798	Line Roller Support	116	10164	19583	Oscillating Slider Bushing
14	10BC5	15769	Key Washer	65	10153	19558	Bail Spring Guide B	117	146WE		Oscillating Pawl Cover
15	10344	15770	Drag Washer A	66	1015E	19568	Bail Spring	118	10MT4	3561	Screw
16	10EAG	19714	Spool Ring Pin	67	10DUU	19570	Spring Guide A Support Collar	119	108W9	9968	O Ring
17	108WD	8291	O Ring	68	1016J	19569	Bail Spring Guide A	120	10AYL	15834	Rear Protector Collar
18	10C19	15771	Drag Washer B	69	10R2F	19715	Bail Spring Guide A Bush	121	10LSC	11633	Screw
19	10BS8	15772	Drag Disk A	70	14865		Bail Trip Lever	122	146W9		Idle Gear (Large)
20	146WU		Spool Bearing Bushing	72	10CYT	8227	Screw	123	146WC		Idle Gear
21	1017T	19640	Drag Disk B	73	146WX		Bail Hold Support Guard	124	146W0		Bearing Water Proof
22	10RC9	19648	Bearing Water Proof	74	146WY		Rotor Guard A	125	10BGG	15815	Bearing Washer
23	1016H	19545	Drag Plate Washer	75	146WV		Rotor	126	104PW	14101	Ball Bearing
24	147FC		Screw	76	147FE		O Ring	127	146VZ		Body Seal
25	109ZN	12491	Spring Holder	77	146W2		Rotor Ring	128	1486B		Drive Gear Assembly
26	10E90	19522	Drag Click Assembly	78	1015M	19534	Screw	129	14814		Washer
27	1480N		Screw	79	101AD	16974	O Ring	130	14A3P		Side Cover Assembly
28	109ZQ	15777	Drag Click Ratchet	80	10148	19612	Roller Clutch Water Proof Cover	131	10A6N	15721	Screw
29	100LX	21656	Drag Cover	81	147FS		Roller Clutch Water Proof	132	10PVM	15819	Screw
30	101DJ	19753	Spool Washer	82	1014F	19607	Roller Clutch Inner	133	10PVN	15820	Screw
31	103MW	15780	Spool Support	83	10DUZ	19532	Roller Clutch Assembly	134	14A92		Handle Assembly
32	103LB	16426	Screw	84	1014X	19539	O Ring	135	14A3R		Handle Shaft Cover Assembly
33	10K30	15781	Nut Lock Plate	85	10ML2	8144	Screw	136	10LAA	13673	O Ring
34	147VW		Bearing Water Proof	86	146W3		Bearing Retainer	137	146WL		Handle Shaft
35	14B4X		Washer	87	10RJF	21491	Ball Bearing	138	14A93		Handle Shank Assembly
36	10S4S	21481	Main Shaft Spacer	88	14A3U		Washer	139	10E85	19598	Handle Shaft Screw
37	146X3		Rotor Nut	89	146W4		Pinion Gear	140	147FX		Handle Knob Water Proof
38	10163	19540	O Ring	90	147FF		Washer	141	104FH	19745	Washer
39	146X4		Rotor Brim	91	147FT		Spacer	142	105BN	10424	Ball Bearing
40	1077Q	7919	Click Spring	92	104PN	10308	Ball Bearing	143	14A3T		Handle Knob Assembly
41	10CH8	8008	Click Pin	93	146W5		Bushing	144	10KX1	11706	Ball Bearing
42	146VW		Bail Spring Cover	94	1014J	19578	Friction Ring	145	103E9	2110	Screw
43	10CYU	9847	Screw	95	10R5T	22047	Idle Gear Spring	146	10LAB	13317	O Ring
44	10DN7	19712	Screw	96	146WA		Idle Gear Shaft	147	1004B	20739	Handle Knob Seal
45	10H0P	5917	Washer	97	10AYR	15710	Body Flange Seal	151	14CTH		Washer
46	146X0		Bail Arm	98	108WP	12469	O Ring				
47	14859		Bail Arm Fin Assembly	99	146WG		Handle Screw Cap				
48	10K7M	15793	Collar	100	14A91		Body Assembly				
49	14A71		Washer	101	10147	19581	Oscillating Guide				
50	147FH		Screw	102	10JAB	16480	O Ring				
51	10PN1	12345	Set Screw	103	146WB		Worm Shaft				
52	10K46	12344	Screw	104	10PDA	11018	Ball Bearing	501	1485A		Bail Arm Fin B Assembly (accessory)
53	10MT2	18570	Screw	105	100XZ	19744	Washer	502	1485B		Handle Shaft (Right) Assembly (accessory)