



MIKE'S REEL REPAIR

Key No.	Parts No.	Parts Name
1	B12-0101	L. S. ring
2	353-6201	L. S. plate screw
3	B12-1801	Frame
4	541-6501	Click button
5	375-9301	Click button washer
6	375-1101	Click claw washer A
7	030-6611	Click claw
8	373-1600	Click claw washer B
9	320-1402	Click claw retainer
10	353-9801	Rod clamp screw
11	341-9701	Rod clamp nut
12	041-5601	Rod clamp
13	342-2111	Rod clamp wing nut
14	375-7403	Ball bearing metal washer
15	633-8811	Ball bearing
16	B12-2101	Click spring retainer
17	160-7922	Click spring
18	351-7701	Click spring screw
19	812-2201	Spool
20	B30-7901	Set plate
21	636-6401	Ball bearing
22	170-7701	Ball bearing retainer
23	750-6012	Pinion gear
24	B11-9802	R. S. plate
25	041-5701	Eccentric jack
26	041-5801	Pinion yoke
27	145-2411	Clutch spring
28	B12-0301	Eccentric cam
29	B12-0601	Eccentric cam spring

Key No.	Parts No.	Parts Name
30	B12-0401	Clutch lever
31	160-8001	Clutch lever lock washer
32	363-5301	Clutch lever screw
33	145-2801	Anti-reverse claw spring
34	B12-0701	Anti-reverse claw
35	B12-0201	Spool adjusting cap metal
36	637-0601	Friction ring
37	B12-7801	Spool adjusting cap
38	B34-3301	Set plate screw
39	B12-1101	Gear shaft
40	375-2901	Drive gear washer
41	B12-1401	Drive gear
42	B12-1501	Drag washer A
43	375-6205	Drag washer B
44	375-6302	Drag washer C
45	375-6204	Drag washer D
46	B26-8401	Spacing sleeve
47	151-8701	Tension spring
48	782-5304	Star drag
49	B17-2801	Handle washer
50	B12-1603	Handle
51	B10-5701	Handle nut
52	371-0604	Handle nut washer
53	320-7601	Handle nut retainer
54	B15-2301	Handle nut plate
55	351-1801	Handle nut plate screw
56	B03-7201	Set plate screw retaining nut
57	B35-2501	Clutch lever screw holder