



## Model 445A700, 445A720



The Kerosene Generator is optional. It does not come with the stove.



### Parts List

No.	Part No.	Description
1.	450-3801	Burner, grate and collar assembly
2.	445-5251	Generator assembly
3.	450C5171	Plunger assembly
4.	445-5321	Base/leg kit*
5.	450A5611	Service parts kit
6.	450B5551	Pump assembly
7.	450A5651	Valve assembly (Less Gen.)
8.	450-422	Fuel bottle assembly (22 fl. oz. bottle capacity) (16 fl. oz. operating capacity)
9.	445-5801	Stove maintenance kit (optional); includes 2, 12, 13 and 14
10.	445-5261	Kerosene generator
11.	450-417	Fuel bottle assembly (17 fl. oz. bottle capacity) (11 fl. oz. operating capacity) (optional/not shown)

\*One leg has a leveling screw which can be used to level the stove on uneven surfaces.