



<u>KEY NO.</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>
24	24-4600 Bail Wire Asm 460L	1182039
24	24-5600 Bail Wire Asm 560L	1182049
27	27-4600 Rotor Cup Asm 460L	1182242
27	27-5600 Rotor Cup Asm 560L	1182264
27A	27A-5600 Bail Pivot Cover	1182327
28	28-5600 Trip Lever	1182403
31	36-750 Screw (2 req.)	1183016
32	32-5600 Bail Spring	1182732
34	34-5600 Bail Arm	1182823
34A	34A-5600 Rotor Bushing (2 req.)	1182846
34B	34B-5600 Pivot Plate	1182856
34C	34C-5600 Pivot Arm	1182882
35	35-5600 Line Roller	1182933
35A	35A-706 Ball Bearing	1182963
38	38-5600 Rotor Nut	1183154
39	39-5600 Spool Shaft	1183223
39A	39A-5600 Locating Pin Clip	1183247
39B	39B-5600 Locating Pin	1183251
43	43N-5600 Crosswind Block	1183432
43A	43A-5600 Spool Shaft Clip	1183426
44	39-4CH Screw (4 req.)	1183179
45	45-4600 Housing Cover Asm 460L	1183506
45	45-5600 Housing Cover Asm 560L	1183513
47	47-460 Spool Asm 460L	1183641
47	47-560 Spool Asm 560L	1183649
47C	47C-5600 Drag Cover	1183688
47D	47D-5600 Line Clip	1183690
48	48-5600 Click Tongue	1183710
51	51-650 Retaining Ring	1183794
52	52-560 Drag Knob Assembly	1183825
56T	56T-650 Drag Washer (Teflon)	1183917
57	57-5600 Drag Washer (Keyed)	1183934
70	70-5600 Eccentric Lever (Left)	1184137
70A	70A-5600 Eccentric Lever (Right)	1184140
70C	70C-5600 Screw	1184143
70D	70D-760L Eccentric O-Ring (2 req.)	1202030
71	71-5600 Eccentric Spring	1184155
72	72-5600 Live Liner Eccentric	1184177
73	73-5600 Live Liner Plate	1184182
74	74-5600 Live Liner Dog	1184186
75	75-5600 Live Liner Dog Spring	1184191
76	76-5600 Trip Spring	1192141
77	77-5600 Trip Lever	1192143
82	82-5600 Rear Housing	1184223
83	83-5600 Rear Drag Ratchet	1184231
83A	83A-5600 Rear Drag Ratchet Washer	1184234
84	84-5600 Rear Drag Click Spring	1184237
84A	84A-5600 Rear Drag Click Retainer	1184240
85	85-5600 Rear Drag Washer	1184245
85A	85A-5600 Rear Keyed Washer	1184247
85B	85B-5600 Rear Eared Washer	1184249
86	86-5600 Rear Drag Spring	1184263
86A	86A-5600 Rear Drag Nut	1184274
87	87-5600 Rear Click Pin	1184281
87A	87A-5600 Rear Click Pin Ring	1184283
88	88-560L Rear Drag Knob	1192175
88A	88A-760L Rear Drag Knob O-Ring	1202031
95B	95B-70 Rotor Locking Plate	1184312
98	98-5600 Clutch Retainer	1184364
98C	98C-5600 Clutch / Sleeve Asm	1192217
117	117-5600 Drive Plate	1184487
132	132-5600 Line Roller Washer	1184590
227	227-5600 Bail Trip Cover	1185050
231	231N-5600 Crosswind Gear	1185088
233	233-560 Bearing Cover	1185146

<u>KEY NO.</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>
1	1-4600 Housing Asm 460L	1180516
1	1-5600 Housing Asm 560L	1180531
2	44-5600Screw (3 req.)	1183455
3	44-710 Screw (3 req.)	1183459
6	6-5600 Drag Washer	1180923
7	7-5600 Keyed Drag Washer	1181019
8	8-5600 Main Gear Assembly	1181090
9	22-750 Screw (2 req.)	1181922
11	36-5600 Screw	1183011
13	63A-25FR Screw	1184057
14	44-4400 Screw (2 req.)	1183452
15	15-460 Handle Asm 460L	1181473
15	15-560 Handle Asm 560L	1181483
19	19-5600 Pinion	1181702
20	20-722 Ball Bearing (2 req.)	1181792
20A	20-6500 Ball Bearing (2 req.)	1181789