


Model/Modèle/Modelo
5017A751, 5017A701



Parts List

No.	5017A701	5017A751	Description
1	5017A2151	5017A2151	Reflector Assy
2	5017B3151	5017B3151	Guard
3	5017-619R	5017-620R	Burner
4	5017A5381	5017A5391	Console
5	N/A	5017-3111	Electronic Ignition Assy
6	5015-3271	5015-3271	Thermocouple
7	5443-1491	5443-1491	Control Knob
8	5017-2181	5017-2181	Gas Tip
9	5410A1381	5410A1381	"O" Ring

Nomenclature

N°	5017A701	5017A751	Désignation
1	5017A2151	5017A2151	Ens. du réflecteur
2	5017B3151	5017B3151	Grille protectrice
3	5017-619R	5017-620R	Brûleur
4	5017A5381	5017A5391	Console
5	non disp.	5017-3111	Ens. allumage électron.
6	5015-3271	5015-3271	Thermocouple
7	5443-1491	5443-1491	Bouton de commande
8	5017-2181	5017-2181	Bec de gaz
9	5410A1381	5410A1381	Joint torique

Lista de Piezas

No.	5017A701	5017A751	Descripción
1	5017A2151	5017A2151	Reflector
2	5017B3151	5017B3151	Protector
3	5017-619R	5017-620R	Quemador
4	5017A5381	5017A5391	Consola
5	N/A	5017-3111	Encendido electrónico
6	5015-3271	5015-3271	Termopar
7	5443-1491	5443-1491	Perilla de control
8	5017-2181	5017-2181	Boquilla de gas
9	5410A1381	5410A1381	Aro "O"