



**NOT ALL PARTS ARE AVAILABLE.**

**KEY NO.**

**DESCRIPTION**

- 1 Housing
- 3 Dog Screw
- 4 Dog
- 4A Silent Dog
- 5 Click Dog Spring
- 6 Drag Washer-HT-100
- 6A Upper Eccentric
- 6B Upper Eccentric Liner
- 6C Silent Eccentric Screw
- 6D Eccentric Spring
- 6E Anti-Reverse Lever
- 6J Silent Dog Lever
- 6L Silent Eccentric

**PART NO.**

- 001 650
- 003 750
- 004 650
- 004A650
- 005 704
- 006 155
- 006A550
- 006B750
- 006B700Z
- 006D710
- 006E750
- 006J750
- 006L650

**KEY NO.**

**DESCRIPTION**

- 7\* Pinion Bushing\*
- 8 Main Gear
- 9A Standard Drive Screw
- 10 Ratchet
- 15 Handle Assembly
- 16A Eccentric Screw (2 req.)
- 17 Seal Washer
- 19 Pinion
- 19A Pinion Spacer
- 20 Bearing
- 20A Bearing
- 21 Bearing Cover
- 22 Spool Click Screw
- 23 Bearing Cover Screw (3 req.)
- 24 Bail Wire
- 27 Rotor
- 31 Bail Arm Screw
- 32 Bail Arm Spring
- 34 Bail Arm
- 34A Bail Arm Bushing
- 35 Line Roller
- 35A Roller Sleeve
- 36 Bail Stud Screw
- 36A Lock Washer
- 37 Rotor Washer
- 38 Rotor Nut
- 39 Crosswind Shaft
- 43 Crosswing Block
- 43A Crosswind Block Plate
- 44 Crosswind Block Screw (2 req.)
- 44A Trip Bumper Screw
- 45 Housing Cover
- 46 Housing Cover Screw (3 req.)
- 47 Spool Complete
- 48 Click Tongue
- 48A Click Tongue Washer
- 49 Click Tongue Spring
- 50 Bail Spring Cover Screw
- 51 Retaining Ring
- 52 Drag Knob
- 56T Drag Washer (Teflon®)
- 57 Drag Washer (Keyed) Small Dia.
- 58 Metal Washer (Octagon)
- 60 Thrust Washer
- 132 Roller Washer
- 224 Transfer Lever
- 225 Crosswind Shaft Bushing
- 226 Bushing Cap Cvoer
- 227 Bail Spring Cover
- 231 Crosswind Gear
- 232 Bearing Cover (Open)
- 233 Bearing Cover (Closed)
- 234 Transfer Lever Screw
- 236 Trip Bumper

**PART NO.**

- 007 750\*
- 008 650
- 009A650
- 010 650
- 015 650N
- 016 910
- 017 650
- 019 650
- 019A650
- 020 704
- 020 722
- 021 750
- 022 750
- 023 750
- 024 650
- 027 650
- 031 750M
- 032 750
- 034 750
- 034A750
- 035 750
- 035A704
- 036 750
- 036A750
- 037 650
- 038 710
- 039 650
- 043 750
- 043A750
- 044 750
- 044 750
- 045 650
- 046 750
- 047 6500
- 048 750
- 048A750
- 049 710
- 050 712
- 051 650
- 052 650
- 056T650
- 057 650
- 058 650
- 060 750
- 132 750
- 224 650
- 225 750
- 226 750
- 227 750
- 231 650
- 232 650
- 233 650
- 234 750
- 236 750

\*Not Shown