




Please order by parts number, not key number
 Veuillez indiquer le numéro de la pièce (Non "Key" No.)

CONVENTIONAL REEL **ACCUDEPTH ICV15L**



Key No.	Parts No.	Parts Name
1	H18-1803	FRAME
2	H00-1703	LEVELWIND
3	G93-9901	WORM SHAFT
4	G05-1701	WORM SHAFT BUSHING
5	G93-4201	WORM SHIELD
6	F65-5501	WORM SHAFT WASHER
7	320-5901	WORM SHAFT RETAINER
8	F51-6501	LEVELWIND PAWL
9	373-1300	LEVELWIND WASHER
10	F40-2801	LEVELWIND NUT
11	G93-1802	CLUTCH LEVER
12	G97-4401	CLUTCH CAM
13	G97-4601	CLUTCH CAM PLATE
14	G19-3701	CLUTCH CAM PLATE SCREW
15	G97-4501	CLUTCH CAM SPRING
16	H13-8303	SPOOL
17	G49-8503	SPOOL BALL BEARING
18	H14-4301	SPOOL PAWL
19	B35-2901	BRAKE COLLAR
20	H36-5107	IC MODULE
21	375-7404	R/S BUSHING WASHER(A)
22	375-7411	R/S BUSHING WASHER(B)
23	E08-8005	R/S BALL BEARING
24	H36-5601	R/S BUSHING RETAINER
25	G11-5001	IC MODULE SCREW
26	H18-2301	FINGER COVER
27	H00-2401	PAWL
28	G93-9301	PAWL SCREW
29	H18-2403	PALMING PLATE
30	G97-4701	KICK LEVER
31	G97-4801	KICK LEVER SPRING
32	H13-9502	DRIVE SHAFT
33	G93-2201	WORM SHAFT GEAR
34	G93-2401	DRIVE SHAFT PLATE
35	E09-6501	WORM SHAFT GEAR WASHER
36	E35-1501	DRIVE SHAFT BUSHING
37	320-8002	DRIVE SHAFT RETAINER
38	G19-3701	DRIVE SHAFT PLATE SCREW(A)
39	G17-1402	DRIVE SHAFT PLATE SCREW(A)
40	G93-4301	RATCHET
41	G93-4401	DRIVE GEAR WASHER

Key No.	Parts No.	Parts Name
42	H18-2501	DRIVE GEAR
43	F79-6102	EARED WASHER(A)
44	H19-0001	DRAG DISC WASHER(A)
45	F79-6303	DRAG LIP WASHER
46	H19-7601	EARED WASHER(B)
47	B36-0306	DRAG DISC WASHER(B)
48	G97-5201	YOKE
49	H18-2601	PINION GEAR
50	B41-1706	YOKE WASHER
51	G85-0301	YOKE SPRING
52	H18-2701	CLUTCH CAM LEVER
53	G08-2301	CLUTCH CAM LEVER PAWL
54	E16-9504	LINE HOLDER
55	H18-2806	L/S PLATE
56	H14-0201	BUSHING
57	H18-0501	BUSHING RETAINER
58	F55-2704	ONE-WAY CLUTCH
61	B05-5201	MECHANICAL BRAKE O RING
62	G27-0901	L/S PLATE SCREW(A)
63	H18-2905	R/S PLATE
64	H56-7301	L/S PLATE SCREW(B)
65	H56-7401	L/S PLATE SCREW(C)
66	375-7501	MECHANICAL BRAKE WASHER(A)
67	B17-5503	MECHANICAL BRAKE WASHER(B)
68	H21-3602	BRAKE ADJ KNOB
69	G93-4802	CLUTCH COLLAR
70	B86-1704	HANDLE BUSHING
71	B55-3801	HANDLE BUSHING WASHER
72	F02-8201	DRAG HOLDER
73	F03-2401	DRAG HOLDER LEAF SPRING
74	150-8901	DRAG SPRING WASHER
75	H00-2115	STAR DRAG
76	F84-9904	DRAG NUT
77	150-9001	HANDLE WASHER
78	H49-0501	HANDLE
79	F84-9904	HANDLE NUT
80	G96-9902	HANDLE CAP
81	375-3003	R/S BUSHING WASHER(C)
82	B53-6104	IC MODULE SCREW WASHER
83	B53-6104	L/S PLATE SCREW(B) WASHER