

MODEL:ASARO 5930

Rev:01

ITEM	DESCRIPTION	SAP #	ITEM	DESCRIPTION	SAP #
1	DRAG KNOB ASSY	1205813	33	BUSHING	1205927
2	SCREW	1205814	34	CLUTCH WASHER	1205928
3	SPOOL RING	1205916	35	SCREW	1200799
4	SPOOL LIP	1205917	36	BEARING COVER	1200800
5	KEY WASHER	1201812	37	BEARING 14×8×3.5	1201850
6	DRAG WASHER	1201813	38	BEARING SLEEVE	1205895
7	EARED WASHER	1205918	39	ONE WAY CLUTCH	1200803
8	SPOOL SUB-ASSY	1205919	40	CLUTCH SPRING	1200805
8A	COMPLETE SPOOL VENTED	1216612	41	PINION GEAR	1205929
8A	COMPLETE SPOOL SOLID	1216613	42	BUSHING	1200797
9	SHEET WASHER	1200771	43	N-R LEVER SPRING	1200869
10	WASHER	1200772	44	N-R LEVER SHAFT	1205898
11	BEARING 10×6×3	1200773	45	SCREW	1200808
12	SLEEVE	1200774	46	N-R LEVER	1205899
13	CLICK GEAR	1201821	47	DUST CAP ASSY	1205900
14	MAIN SHAFT	1205920	48	BEARING 12×8×2.5	1201803
15	SCREW	1200784	49	DRIVE GEAR	1205930
16	BAIL HOLDER	1205882	50	GEAR WASHER	1200798
17	BAIL WIRE SUB-ASSY	1205921	51	GEAR WASHER	1200876
18	LINE SLIDER WASHER	1200780	52	BODY COVER ASSY	1205931
19	LINE ROLLER	1205884	53	SCREW	1200902
20	BEARING 7×4×2.5	1200781	54	SCREW	1200816
21	LINE ROLLER COLLAR	1205885	55	SCREW	1200817
22	BAIL ARM	1205886	56	HANDLE ASSY	1205906
23	SCREW	1205887	57	SCREW	1200819
24	SCREW	1200787	58	O/S SLIDER	1205932
25	ROTOR COVER	1205922	59	O/S GEAR	1201873
26	BAIL SPRING	1205923	60	BEARING 10×6×2.5	1200822
27	BAIL ARM GUIDE	1205889	61	SCREW	1205909
28	TRIP PLUNGER	1205924	62	O/S SLIDER PLATE	1205933
29	ROTOR SUB-ASSY	1216614	63	SCREW	1205934
30	SCREW	1200794	64	REAR COVER	1205935
31	ROTOR NUT RETAINER	1200795	65	INNER COVER	1205936
32	ROTOR NUT	1205926	66	BODY ASSY	1205937

EXPLODED VIEW

