



Please specify reel model number and number in reel foot when ordering parts.

Ambassadeur Blue Max - L 18 00

Vid beställning av reservdelar bör alltid rulltyp och nummerbeteckning under rullfoten anges

1140451

34-12618-1

ITEM#	PART #	DESCRIPTION	ITEM#	PART #	DESCRIPTION
1	1141542	RIGHT SIDE PLATE	38	1134460	SCREW
2	1134430	MAG DIAL	39	1138854	SPRING
3	1134431	CLICK SPRING	40	1138855	KICK LEVER
4	1134432	O-RING	41	1138856	CLUTCH CAM
5	1134433	CAM CURVE A	42	1153300	LEFT SIDE PLATE
6	1134434	CAM CURVE B	43	1134492	SCREW
7	1138838	LINE REJECTER	44	1134465	O-RING
8	1134436	SCREW	45	1134493	THUMB SCREW
9	1134437	COIL SPRING	46	1104812	O-RING
10	1134438	SCREW	47	1065949	BEARING
11	1134439	MAGNET HOLDER	48	1153297	WASHER
12	1134440	WASHER	50	1153298	WASHER
13	1141515	BEARING	51	1141522	BRAKE KNOB
14	1134442	LOCK RING	52	1141524	BEARING
15	1141517	SPOOL	53	1134468	RETAINER
16	1104799	RETAINER	54	1134469	MAIN GEAR SHAFT PLATE
17	1134444	BUSHING	55	1104820	SCREW
18	1134486	LINE GUIDE	56	1138860	MAIN GEAR SHAFT
19	1134446	PAWL	57	1065960	LEVEL WIND GEAR
20	1134447	WASHER	58	1134471	RATCHET
21	1134487	LINE GUIDE NUT	59	1065962	DRAG WASHER
22	1095574	WORM SHAFT TUBE	60	1138861	MAIN GEAR
23	1138839	WORM SHAFT	61	1134473	DRAG WASHER
24	1134450	WASHER	62	1134474	PRESSURE WASHER
25	1134451	GEAR	63	1134475	IAR BEARING
27	1138840	FRONT COVER	64	1134476	IAR SLEEVE
28	1134453	SCREW	65	1134477	BALL BEARING
29	1134454	LINE GUIDE SHAFT	66	1134478	WASHER
30	1134492	SCREW	68	1065971	SPRING WASHER
31	1153299	FRAME	69	1134479	WASHER
32	1138846	THUMBAR	70	1141546	STAR WHEEL
33	1138849	YOKE	71	1065974	SPRING WASHER
34	1104810	YOKE SPRING	72	1153301	HANDLE
35	1138852	PINION	73	1138865	HANDLE NUT
36	1134458	BUSHING	74	1141541	HANDLE NUT COVER
37	1138853	CLUTCH SPRING	75	1134501	SCREW

REEL REPAIR

