


DIAGRAM



Please specify reel model and part number when ordering parts.

ENDEUR EN2F

PART#	PARTS NAME	PART#	PARTS NAME	PART#	PARTS NAME
1071789	Drag Knob	72056	Bail S/P Shaft	72099	Tail Shaft
72002	Drag Nut	1071814	Bail S/P Cover	1071829	Handle Cap Screw
72004	Drag Spring	72060	Bail S/P Cover S/C	72102	Screw Cap W/S
72006	Drag Knob Under Cap	1071797	Bail Ass'y	72103	O/S Gear
72008	Under Cap Retainer	1071801	Line Roller	72105	O/S Slider
72010	Under Cap Retainer S/C	72068	Bail W/S	72107	O/S Slider S/C
72012	Drag Click Spring	1071805	Arm Lever	72108	Body Bush
72014	Drag Clicker	72071	Bail Screw	72110	Drive Gear
72015	Spool Ring	72072	Kick Lever	72112	Drive Gear ADJ W/S
72017	Drag "D" Washer	72078	Kick Lever S/P	72113	Ball Bearing
72019	Drag "A" Washer	1071810	Kick Lever Cover	1071840	Body Cover
72021	Drag "B" Washer	72084	Cover S/C	1071842	Body Cover S/C
1071758	Spool Unit	72085	Bearing Plate S/C	72119	S/Lever S/P
72029	Click Washer	72086	Bearing Plate	1071848	IAR Lever
72030	Click Gear	72088	Ball Bearing	72122	Stopper Lever S/C
72032	Main Shaft	72089	Bearing W/S	1071844	Body Cap
72038	E - Clip	72091	O/Way Clutch B/B	1071846	Body Cap S/C
72039	Rotor "D" Washer	72093	Clutch Bush	1071825	Handle Ass'y
1071821	Rotor	72095	Pinion Gear	72123	Rotor Nut
72049	Balance Weight	1071836	Body		
72053	Bail Spring				