



ITEM#	PARTS DESCRIPTION	INS40	ITEM#	PARTS DESCRIPTION	INS40
1	Drag Knob Assembly	1347039	38	Trip Bushing	1126272
2	Spool Assembly	1347999	39	Trip Spring	1119106
3	Spool	1348000	40	Bail Arm Cover	1348002
4	Line Clip	1252739	41	Screw	1346956
5	Line Clip Shim	1259476	42	Spring	1346982
6	Line Clip Spring	1257318	43	O-Ring	1206550
7	Keyed Washer(3req)	1252691	44	Damper Holder	1346983
8	Spool Washer	1126369	45	Screw(3req)	1126326
9	Carbon Washer(4req)	1126368	46	Pinion Cover	1346984
10	Spool Washer	1256940	47	Bearing 7X13X4(4req)	1252717
11	Clicker Holder	1257317	48	Bearing Holder	1252718
12	Spool Clicker	1256941	49	Clutch Assembly	1252719
13	Spool Bottom	1252694	50	Pinion	1347981
14	Retaining Clip	1252696	51	Clutch Spring	1252716
15	Spool Shim Thick(2req)	1178953	52	Handle Assembly	1348003
16	Main Shaft Sleeve	1252698	53	Screw(4req)	1125961
17	Plastic Bushing	1252753	54	Body Trim(2req)	1347047
18	Main Shaft Washer	1252700	55	C-Clip(2req)	1252726
19	Main Shaft	1347966	56	Shim	1347983
20	Rotor Set Screw	1126258	57	Drive Gear	1346963
21	Rotor Nut	1259462	58	Screw	1126275
22	POM Bushing	1259463	59	Bushing	1108938
23	Rotor Set Plate	1346951	60	Oscillation Gear	1347984
24	Line Roller Screw	1126261	61	Washer	1253702
25	Bail Arm	1347042	62	Oscillation Slider	1347985
26	Ball Bearing(2req)	1112125	63	Screw	1126275
27	Washer	1110165	64	Oscillation Guide	1346965
28	Line Roller	1252705	65	Insert	1347048
29	Bail Assembly	1347967	66	Body Cover	1348004
30	Bail Arm Screw(2req)	1126379	67	Gear Box	1348005
31	Bushing(2req)	1188261	68	Reduction Gear	1346968
32	Bail Holder	1347043	69	Gear Holder	1348006
33	O-Ring	1252708	70	Oscillation Cover	1348007
34	E-Clip	1252707	71	Screw(2req)	1126084
35	Rotor	1348001	72	Dust Cap	1347052
36	Trip Bar	1347979	73	Screw	1085599
37	Trip Linkage	1252713			