



Please specify reel model number and number in reel foot when ordering parts.

Ambassadeur Blue Max 18 01

Vid beställning av reservdelar bör alltid rulltyp och nummerbeteckning under rullfoten anges

1140450

34-12617-2

ITEM#	PART #	DESCRIPTION	ITEM#	PART #	DESCRIPTION
1	1141512	LEFT SIDE PLATE	39	1104807	SPRING
2	1134430	MAG DIAL	40	1134461	KICK LEVER
3	1134431	CLICK SPRING	41	1160981	CLUTCH CAM
4	1134432	O-RING	42	1141520	RIGHT SIDE PLATE
5	1134433	CAM CURVE A	43	1134492	SCREW
6	1134434	CAM CURVE B	44	1134465	O-RING
7	1134435	LINE REJECTER	45	1134493	THUMB SCREW
8	1134436	SCREW	46	1104812	O-RING
9	1134437	COIL SPRING	47	1065949	BUSHING
10	1134438	SCREW	48	1153297	WASHER
11	1134439	MAGNET HOLDER	50	1153298	WASHER
12	1134440	WASHER	51	1141522	BRAKE KNOB
13	1141515	BEARING	52	1141524	BEARING
14	1134442	LOCK RING	53	1134468	RETAINER
15	1141517	SPOOL	54	1134469	MAIN GEAR SHAFT PLATE
16	1104799	RETAINER	55	1104820	SCREW
17	1134444	BUSHING	56	1134470	MAIN GEAR SHAFT
18	1134486	LINE GUIDE	57	1065960	LEVEL WIND GEAR
19	1134446	PAWL	58	1134471	RATCHET
20	1134447	WASHER	59	1065962	DRAG WASHER
21	1134487	LINE GUIDE NUT	60	1134472	MAIN GEAR
22	1095574	WORM SHAFT TUBE	61	1134473	DRAG WASHER
23	1134449	WORM SHAFT	62	1134474	PRESSURE WASHER
24	1134450	WASHER	63	1134475	IAR BEARING
25	1134451	GEAR	64	1134476	IAR SLEEVE
27	1134452	FRONT COVER	65	1134477	BALL BEARING
28	1134453	SCREW	66	1134478	WASHER
29	1134454	LINE GUIDE SHAFT	68	1065971	SPRING WASHER
30	1134492	SCREW	69	1134479	WASHER
31	1141518	FRAME	70	1141525	STAR WHEEL
32	1134456	THUMB BAR	71	1065974	SPRING WASHER
33	1138560	YOKE	72	1141540	HANDLE
34	1104810	YOKE SPRING	73	1138561	HANDLE NUT
35	1134457	PINION	74	1141541	HANDLE NUT COVER
36	1160979	FLIPPING SWITCH	75	1134501	SCREW
37	1104804	CLUTCH SPRING			
38	1134460	SCREW			