



CLX-450L PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001656	MAIN BODY ASSY	705	17050013	TRANSMISSION GEAR
105	11050006	WORM SHAFT BUSHING	706	17060009	TRANSMISSION GEAR
105-1	11050007	WORM SHAFT BUSHING	707	17070004	TRANSMISSION GEAR
117	11170012	CLICK PAWL SPRING	710	17100059	LINE GUIDE ASSY
200	12001185	HANDLE SIDE PLATE	712	17120021	WORM SHAFT
201	12010001	ANTI-RE PAWL	713	17130004	LINE GUIDE PAWL CAP
207	12070090	HOLDED PLATE	715	17150009	LINE GUIDE PAWL
215	12150030	HOLD PLATE BUSHING	800	18000021	CLUTCH SHAFT
215-1	12150015	HOLD PLATE BUSHING	801	18010007	CLUTCH SPRING
216	12160001	ANTI-RE PAWL SPRING	802	18020015	CLUTCH BAR
300	13001002	VICE SIDE PLATE	804	18040001	CLUTCH SLIDER
302	13020002	WASHER	805	18050001	PINION GEAR YOKE
302-1	13020005	BUSHING	806	18060001	YOKE SPRING
303	13030005	CLICK BUTTON	900-4	29000001	E RETAINER
304	13040001	CLICK PAWL	900-6	29000006	C RETAINER
305	13050007	CLICK PAWL SPRING	901-4	19010001	C RETAINER
400	14000297	SPOOL ASSY.	920-10	0920108	WASHER
401	14010026	SPOOL CLICK GEAR	920-2	0920105	WASHER
500	15000349	HANDLE ARM ASSY	920-23	0920157	WASHER
516	15160002	HANDLE NUT RETAINER	920-4	0920114	WASHER
600	16000093	CAST CONTROL CAP	920-5	0920339	WASHER
609	16090004	DRAG SPRING WASHER	920-6	0920085	WASHER
610	16100010	DRAG WASHER	920-7	0920066	WASHER
610-1	16100032	DRAG WASHER	920-8	0920315	WASHER
611	16110005	EARED WASHER	920-9	0920283	WASHER
612	16120027	KEY WASHER	930-1	09301187	SCREW
612-1	16120029	KEY WASHER	930-12	0930651	SCREW
614	16140003	DRAG WASHER	930-14	0930544	SCREW
615	16150021	STAR DARG	930-16	09301186	SCREW
617	16170023	DRIVE GEAR SHAFT BUSHING	930-17	09301022	SCREW
617-1	16170018	DRIVE GEAR SHAFT BUSHING	930-19	0930196	SCREW
700	17000200	DRIVE GEAR	930-2	0930219	SCREW
701	17010079	DRIVE GEAR SHAFT	930-21	0930202	SCREW
702	17020322	PINION GEAR	930-7	0930229	SCREW
703	17030005	WORM SHAFT GUARD	940-2	0940024	O RING
704	17040037	LINE GUIDE SUPPORT BAR			