



CMR-463 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	31000614	BODY ASSY.(with shaft)	400	34000778	SPOOL ASSY
102	31020148	BODY FOOT	400-1	34000777	SPOOL
104	31040039	MAIN SHAFT SCREW	404	34040027	HANDLE KNOB
115	31150005	BUSHING	405	34050016	HANDLE KNOB RIVET
207	32070004	SCREW MAT	410	34100066	SPOOL COVER
300	33000116	DRAG LEVER	425	34250001	SILENT SPRING
303	33030008	HOLDED PLATE	910	0910438	BEARING
304-1	33040029	CLICK PIN, DRAG LEVER	920	0920475	WASHER
304-2	33040031	CLICK PIN, SPOOL	920	0920474	WASHER
305	33050019	SPRING	920	0920470	WASHER
310	33100034	DRAG WASHER	920	0920450	WASHER
315	33150015	DISK BREAK	920	09201002	WASHER
324	33240006	ANTI-REVERSE PAWL	930	0930086	SCREW
326	33260002	BRAKE	930	0930872	SCREW
327	33270007	PACKING PIN	930	0930188	SCREW
329	33290007	COMPRESSION SPRING	930	09301170	SCREW
333	33330003	DRAG COMPRESSION SPRING	930	09301178	SCREW
340	33400007	DRAG WASHER RETAINER	940	0940006	O RING
341	33410001	BUSHING, BEARING	940	0940029	O RING
342	33420003	ANTI-RE SPRING	940	0940048	O RING
343	33430001	ANTI-RE PAWL BUSHING			