



CY-200 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	41004444	MAIN BODY ASSY	705-1	47050009	TRANSMISSION GEAR
105	41050003	WORM SHAFT BUSHING	711	47110037	GUIDE SLIDE BASE ASSY.
117	11170012	CLICK PAWL SPRING	712	47120007	WORM SHAFT
119	41190046	BODY COVER	713	47130005	LINE GUIDE PAWL CAP
200	42000322	HANDLE SIDE PLATE	715	47150002	LINE GUIDE PAWL
202	42020002	RATCH	720	47200004	DRIVE GEAR SHAFT BUSHING
207	42070001	HOLDED PLATE	725	47250001	TRANSMISSION GEAR PIN
220	42200008	SIDE PLATE HOLDED SCREW	800	48000005	CLUTCH SHAFT
300	43000561	VICE SIDE PLATE	801	48010004	CLUTCH SHAFT SPRING
302	43020004	WASHER	804	48040004	CLUTCH SLIDER
313	43130001	VICE SIDE PLATE FIXER	804-1	48040008	CLUTCH SLIDER
314	43140001	VICE SIDE PLATE CONTROL PIN	805	48050007	PINION GEAR YOKE
315	43150001	VICE SIDE HOLDED PLATE	806	48060002	YOKE SPRING
400	44000097	SPOOL ASSY.	807	48070006	YOKE BRAKED PLATE
401	44010003	SPOOL CLICK GEAR	808	48080004	YOKE BRAKED PLATE SPRING
412	24120038	SPOOL BUSHING	809	48090007	CLUTCH BAR WASHER
500	45000124	HANDLE ASSY.	812	48120003	BRAKED PLATE HOLDER
516	45160024	HANDLE NUT RETAINER	813	48130001	CLUTCH BAR CAP
600	46000022	CAST CONTROL CAP	900	29000001	E RETAINER
608	46080002	DRAG WASHER RETAINER	900	19000002	E RETAINER
609	16090009	DRAG SPRING WASHER	900	49000001	E RETAINER
610	16100018	DRAG WASHER	910	0910236	BALL BEARING
610-1	16100037	DRAG WASHER	910	0910170	BALL BEARING
610-2	16100038	DRAG WASHER	910	0910005	BALL BEARING
611	16110006	EARED WASHER	920	0920105	WASHER
612	16120027	KEY WASHER	920	0920292	WASHER
612-1	16120030	KEY WASHER	920	0920014	WASHER
615	46150118	STAR DARG ASSY.	930	0930378	SCREW
618	46180002	SPACER	930	0930547	SCREW
619	46190003	WASHER	930	0930763	SCREW
700	47000017	DRIVE GEAR	930	0930368	SCREW
701	47010009	DRIVE GEAR SHAFT	930	0930146	SCREW
702	47020030	PINION GEAR	930	0930226	SCREW
703	47030014	WORM SHAFT GUARD	930	0930704	SCREW
705	47050008	TRANSMISSION GEAR	940	0940003	O RING