


SPINNING REEL **403A**



KEY NO. 2 ~ 8
6-732-2001

SPPOOL ASSEMBLY

Key No.	Parts No.	Parts Name
1	740-3002	Drag knob
2	170-4001	Drag washer retainer
3	374-7901	Drag D washer
4	370-6901	Disc washer
5	375-5302	Drag A washer
*6	513-0311	Spool
7	141-1611	Spool click claw
8	320-9701	Spool click claw retainer
9	374-6401	Spool washer
10	374-6400	Spool adjusting washer
11	711-1801	Main shaft
12	481-1601	Oscillating slider
13	490-4301	Oscillating slider pin
14	340-6602	Rotor nut
15	160-1612	Rotor washer
16	201-9003	Rotor
17	570-9511	Bail kick lever
18	140-6231	Bail kick lever spring
19	361-1512	Bail kick lever screw

Key No.	Parts No.	Parts Name
20	140-9231	Bail spring
21	230-7001	Arm lever
22	363-1311	Arm lever screw
23	341-9901	Bail nut
24	160-0121	Bail washer
25	250-3821	Line roller
26	725-6801	Bail
27	352-0401	Bail holder screw
28	371-6400	Pinion washer
29	402-6511	Pinion gear
30	700-8905	Body
31	413-5311	Drive gear
32	371-2800	Drive gear washer
33	706-4004	Body cover
34	111-5501	Anti-reverse claw
35	141-6111	Anti-reverse claw spring
36	350-1931	Anti-reverse claw screw
37	351-8501	Body cover screw
38	746-5301	Handle

*Not sold separately. See Spool Assembly.