


# SPINNING REEL 404A



**KEY NO. 2 ~ 10**  
**6-732-7201**

**SPOOL ASSEMBLY**

Key No.	Parts No.	Parts Name
1	003-4426	Drag knob
2	170-4001	Drag washer retainer
3	374-8001	Drag D washer
4	370-6901	Disc washer
5	375-5302	Drag A washer
*6	513-0402	Spool
7	030-6401	Spool click claw
8	352-0601	Spool click claw screw
9	142-0011	Spool click claw spring
10	320-9701	Spool click claw spring retainer
11	371-4410	Spool adjusting washer
12	371-4411	Spool washer
13	711-2701	Main shaft
14	481-1901	Oscillating slider
15	121-6301	Oscillating slider pin
16	340-6602	Rotor nut
17	201-9902	Rotor
18	570-8602	Bail kick lever
19	140-6231	Bail kick lever spring
20	361-1512	Bail kick lever screw
21	007-6201	Bail

Key No.	Parts No.	Parts Name
22	351-8501	Bail holder screw
23	250-1921	Line roller
24	230-8301	Arm lever
25	340-9101	Bail nut
26	140-9231	Bail spring
27	361-6413	Arm lever screw
28	706-6502	Body
29	371-6400	Pinion washer
30	402-8211	Pinion gear
31	413-7511	Drive gear
32	370-7500	Drive gear washer
33	063-1102	Body cover
34	111-3501	Anti-reverse claw
35	144-0001	Anti-reverse claw spring
36	351-6102	Anti-reverse claw screw
37	461-2201	Anti-reverse cam
38	150-1751	Anti-reverse lever washer
39	540-3711	Anti-reverse lever
40	350-1931	Anti-reverse lever screw
41	351-8501	Body cover screw
42	747-0301	Handle

\*Not sold separately. See Spool Assembly.