


FLY REEL **732**



KEY NO. 1 ~ 6
6-732-3011

SPOOL ASSEMBLY

KEY NO. 9 ~ 11
6-781-6601

STAND ASSEMBLY

Key No.	Parts No.	Parts Name
1	353-0001	Cover screw
2	130-4701	Cover
3	375-3801	Cover washer
4	144-1801	Spool stopper spring
5	541-3401	Spool stopper
6	732-3111	Spool
7	353-3501	Screw
8	560-4701	Ring
9	610-3401	Stand
10	050-8801	Stand pillar
11	353-3601	Stand screw
12	320-8901	Click gear retainer
13	050-8901	Pillar
14	310-1401	Line guard

Key No.	Parts No.	Parts Name
15	144-2901	Friction spring
16	171-3001	Body ring
17	320-7601	Click spring retainer
18	151-5702	Click spring
19	750-4101	Click gear
20	320-5901	Click claw retainer
21	030-5201	Click claw
22	461-3801	Cam
23	706-4501	Body
24	151-5301	Click lever washer
25	541-3501	Click lever
26	352-2501	Click lever screw
27	353-3501	Screw