


SPINNING REEL 8350HRL



KEY NO. 1 ~ 13
6-733-7601

SPOOL ASSEMBLY

Key No.	Parts No.	Parts Name
1	740-4201	Drag knob
2	171-7701	Drag washer retainer
3	374-4802	Drag washer A
4	373-3701	Drag washer B
5	373-3603	Drag washer C
6	373-3704	Drag washer D
7	514-3401	Spool
8	145-2101	Spool click claw spring
9	B07-5301	Spool click claw
10	320-5901	Spool click claw retainer
11	375-5701	Spool washer
12	151-7211	Spool metal leaf spring
13	720-1721	Spool metal
14	711-4501	Main shaft
15	481-1501	Oscillating slider
16	351-5311	Oscillating slider screw
17	340-6602	Rotor nut
18	202-1401	Rotor
19	571-0001	Bail kick lever
20	143-4801	Bail kick lever spring
21	361-8202	Bail kick lever screw
22	141-0651	Bail spring
23	341-2701	Bail nut
24	231-0431	Arm lever
25	361-8532	Arm lever screw

Key No.	Parts No.	Parts Name
26	250-1921	Line roller
27	725-8601	Bail
28	351-6401	Bail holder screw
29	373-7804	Pinion washer A
30	372-7600	Pinion washer B
31	633-5521	Ball bearing ret. washer
32	350-1931	Ball bearing ret. washer screw
33	631-6901	Ball bearing
34	403-2101	Pinion gear
35	701-3904	Body
36	460-6821	Anti-reverse cam
37	142-2801	Anti-reverse cam spring
38	541-3132	Anti-reverse lever
39	351-4701	Anti-reverse lever screw
40	413-4501	Oscillating gear
41	414-1201	Drive gear
42	370-5100	Drive gear washer
43	706-9604	Body cover
44	111-3411	Anti-reverse claw
45	143-9601	Anti-reverse claw spring
46	351-7701	Anti-reverse claw screw
47	351-6401	Body cover screw
48	746-1341	Handle
49	501-8501	Handle screw holder
50	B22-3401	Handle screw