


SPINNING REEL 8450HRL



KEY NO. 1 ~ 12
6-734-2301

SPOOL ASSEMBLY

Key No.	Parts No.	Parts Name
1	007-8414	Drag knob
2	170-4601	Drag washer retainer
3	373-3501	Drag D washer
4	373-3701	Disc washer
5	373-3601	Drag A washer
6	373-3411	Drag washer A
7	514-4701	Spool
8	030-6802	Spool click claw
9	145-2101	Spool click claw spring
10	352-0601	Spool click claw screw
11	375-5701	Spool washer
12	007-8561	Spool metal
13	007-6461	Main shaft
14	480-6301	Oscillating slider
15	352-1501	Oscillating slider screw
16	340-5842	Rotor nut
17	372-9202	Rotor retaining washer
18	201-7912	Rotor
19	140-9231	Bail spring
20	230-8301	Arm lever
21	361-6413	Arm lever screw
22	007-6201	Bail
23	250-1921	Line roller
24	340-9101	Bail nut

Key No.	Parts No.	Parts Name
25	351-6401	Bail holder screw
26	570-6411	Bail kick lever
27	142-5321	Bail kick lever spring
28	363-1501	Bail kick lever screw
29	320-2911	Ball bearing ret. ring
30	631-6901	Ball bearing
31	403-2501	Pinion gear
32	007-6163	Body
33	540-3711	Anti-reverse lever
34	350-1931	Anti-reverse lever screw
35	460-6821	Anti-reverse cam
36	142-2801	Anti-reverse cam spring
37	401-4801	Oscillating gear
38	401-3701	Oscillating pinion
39	414-2001	Drive gear
40	370-9923	Drive gear washer
41	007-6504	Body cover
42	110-7401	Anti-reverse claw
43	142-5411	Anti-reverse claw spring
44	350-1931	Anti-reverse claw screw
45	351-6401	Body cover screw
46	372-4601	Handle washer
47	351-5531	Handle screw
48	007-6653	Handle