


SPINNING REEL GS-10X



Key No.	Parts No.	Parts Name
1	441-5301	Drag knob
2	151-7301	Drag spring washer
3	375-6001	Drag D washer
4	375-5902	Disc washer
5	733-4704	Spool
6	B07-5302	Spool click claw
7	320-5901	Spool click claw retainer
8	144-1211	Spool click claw spring
9	375-5701	Spool washer
10	720-1331	Spool metal
11	151-7211	Spool metal leaf spring
12	711-4202	Main shaft
13	636-7602	Oscillating support
14	B12-8201	Oscillating slider screw
15	341-9201	Rotor nut
16	202-0921	Rotor
17	145-0701	Bail kick cam spring
18	571-0611	Bail kick cam
19	354-0701	Bail kick cam screw
20	571-0501	Bail kick lever
21	041-7021	Bail kick lever cover
22	351-7701	Bail kick lever cover screw
23	145-2601	Bail spring
24	041-6901	Bail spring cover
25	351-7701	Bail spring cover screw
26	725-8011	Bail
27	363-4301	Bail holder screw
28	363-4411	Bail screw
29	375-4301	Bail washer
30	231-2821	Arm lever

Key No.	Parts No.	Parts Name
31	363-4301	Arm lever screw
32	501-4411	Roller collar
33	250-1921	Line roller
34	280-8901	Ratchet
35	145-0501	Anti-reverse claw spring
36	321-0801	Ball bearing ret. washer
37	351-0901	Ball bearing ret. washer screw
38	636-6401	Ball bearing
39	403-0701	Pinion gear
40	701-3303	Body
41	041-8201	Cam kick plate
42	351-6601	Cam kick plate screw
43	111-8301	Anti-reverse claw
44	051-6801	Anti-reverse claw plate
45	363-8801	Anti-reverse claw screw
46	461-7302	Anti-reverse cam
47	145-2701	Anti-reverse cam spring
48	371-6903	Anti-reverse lever washer
49	541-6801	Anti-reverse lever
50	353-4401	Anti-reverse lever screw
51	637-5701	Ball bearing
52	414-0012	Drive gear
53	481-1801	Oscillating slider
54	375-8500	Drive gear washer
55	637-5701	Ball bearing
56	706-8901	Body cover
57	353-0001	Body cover screw
58	B03-4803	Handle screw cap
59	B15-8301	Handle