




SPINNING REEL GS-15X



| Key No. | Parts No. | Parts Name |
|---------|-----------|-----------------------------|
| 1 | 740-3801 | Drag knob |
| 2 | 170-4601 | Drag washer retainer |
| 3 | 374-4802 | Drag D washer |
| 4 | 373-3701 | Disc washer |
| 5 | 373-3603 | Drag A washer |
| 6 | 373-3704 | Drag washer A |
| 7 | 733-5404 | Spool |
| 8 | B07-5302 | Spool click claw |
| 9 | 320-5901 | Spool click claw retainer |
| 10 | 144-1211 | Spool click claw spring |
| 11 | 375-5701 | Spool washer |
| 12 | 720-1721 | Spool metal |
| 13 | 151-7211 | Spool metal leaf spring |
| 14 | 711-4601 | Main shaft |
| 15 | 637-0102 | Oscillating support |
| 16 | 351-5311 | Oscillating slider screw |
| 17 | B10-5701 | Rotor nut |
| 18 | 202-1131 | Rotor |
| 19 | 145-0701 | Bail kick cam spring |
| 20 | 571-0821 | Bail kick cam |
| 21 | 354-0701 | Bail kick cam screw |
| 22 | B26-3101 | Bail kick lever |
| 23 | 041-7221 | Bail kick lever cover |
| 24 | 351-7701 | Bail kick lever cover screw |
| 25 | 145-1011 | Bail spring |
| 26 | 041-7301 | Bail spring cover |
| 27 | 351-7701 | Bail spring cover screw |
| 28 | 725-8111 | Bail |
| 29 | 363-5201 | Bail holder screw |
| 30 | 353-1811 | Bail screw |
| 31 | 375-1001 | Bail washer |
| 32 | 231-2901 | Arm lever |

| Key No. | Parts No. | Parts Name |
|---------|-----------|--------------------------------|
| 33 | 363-5201 | Arm lever screw |
| 34 | 501-1601 | Roller collar |
| 35 | 250-4221 | Line roller |
| 36 | 501-9901 | Spring holder |
| 37 | 145-0901 | Anti-reverse claw spring |
| 38 | 280-9001 | Ratchet |
| 39 | 501-9801 | Spacer |
| 40 | 321-0901 | Ball bearing ret. washer |
| 41 | 351-0901 | Ball bearing ret. washer screw |
| 42 | 635-4801 | Ball bearing |
| 43 | 403-2201 | Pinion gear |
| 44 | 701-4004 | Body |
| 45 | B22-3101 | Cam kick plate |
| 46 | 351-6601 | Cam kick plate screw |
| 47 | 111-8201 | Anti-reverse claw |
| 48 | 041-7101 | Anti-reverse claw plate |
| 49 | 363-9301 | Anti-reverse claw screw |
| 50 | 461-7104 | Anti-reverse cam |
| 51 | 144-0321 | Anti-reverse cam spring |
| 52 | 371-6903 | Anti-reverse lever washer |
| 53 | 541-6801 | Anti-reverse lever |
| 54 | 353-4401 | Anti-reverse lever screw |
| 55 | 637-5701 | Ball bearing |
| 56 | 414-1312 | Drive gear |
| 57 | 481-2101 | Oscillating slider |
| 58 | 375-8500 | Drive gear washer |
| 59 | 637-5701 | Ball bearing |
| 60 | 706-9702 | Body cover |
| 61 | 353-0001 | Body cover screw |
| 62 | B03-4803 | Handle screw cap |
| 63 | B15-8401 | Handle |