


SPINNING REEL

GS-60 & GS-60SC



KEY NO. 2 ~ 10
6-733-1402

SPOOL ASSEMBLY

KEY NO. 56 ~ 59
6-747-2002

HANDLE ASSEMBLY

SPECIAL PART FOR GS-60SC
6-280-7112

RATCHET

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	000-8241	Drag knob	31	270-7111	Click gear
2	170-4511	Drag washer retainer	32	050-5101	Ball bearing ret. washer
3	372-7812	Drag D washer	33	635-5001	Ball bearing
4	372-9011	Disc washer	34	403-0801	Pinion gear
5	375-5401	Drag A washer	35	351-6601	Ball bearing ret. washer screw
6	372-7701	Drag washer A	36	144-0321	Anti-reverse cam spring
7	733-1502	Spool	37	363-3601	Anti-reverse claw screw
8	B07-8201	Spool click claw	38	375-5200	Anti-reverse claw washer
9	363-8401	Spool click claw retainer	39	770-0931	Anti-reverse claw
10	145-2101	Spool click claw spring	40	461-5102	Anti-reverse cam
11	376-1701	Spool washer	41	701-1101	Body
12	710-2214	Main shaft	42	373-2700	Anti-reverse lever washer
13	481-1011	Oscillating slider	43	541-6101	Anti-reverse lever
14	351-8901	Oscillating slider screw	44	352-2501	Anti-reverse lever screw
15	340-8301	Rotor nut	45	374-5400	Oscillating gear washer
16	201-7603	Rotor	46	412-3612	Oscillating gear
17	144-2201	Bail spring	47	636-6011	Ball bearing
18	633-0701	Bail spring cover	48	414-0101	Drive gear
19	351-1801	Bail spring cover screw	49	371-2800	Drive gear washer
20	363-3111	Bail screw	50	636-6011	Ball bearing
21	375-1101	Bail washer	51	706-7801	Body cover
22	231-1901	Arm lever	52	351-6401	Body cover screw
23	130-3201	Bail holder cap	53	501-8401	Handle screw holder
24	363-1901	Arm lever screw	54	363-8611	Handle screw
25	501-2001	Roller collar	55	363-4702	Handle screw cap
26	250-4321	Line roller	56	747-2411	Handle arm
27	351-6401	Bail holder screw	57	747-2501	Handle stand
28	725-1220	Bail	58	342-3101	Handle arm ret. nut
29	280-5401	Ratchet	59	353-9101	Handle arm ret. nut screw
30			60	375-7701	Rotor washer