


# JUPITER-Z3500T-3B / 4000T-3B



Key No.	Parts No.	Parts Name
2-9	F72-8001	SPOOL
1	F32-9501	DRAG KNOB
2	171-7701	DRAG WASHER RET
3	F09-4901	KEY WASHER
4	E13-6003	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	F09-4701	SPOOL WASHER
11	E46-2701	CLICK GEAR
12	F61-9501	MAIN SHAFT
13	F09-1301	OSC SLIDER
14	352-1502	OSC SLIDER SCREW
15	340-6602	ROTOR NUT
16	F31-3905	ROTOR
17	B67-9304	LINE ROLLER SCREW
18	F61-9201	BAIL ARM
19	B84-2102	BAIL ARM SCREW
19	E15-8602	SIDE COVER SCREW B
20	F44-6302	LINE ROLLER COLLAR
21	F44-6202	LINE ROLLER WASHER
22	F47-3401	LINE ROLLER BUSHING
23	F45-4901	LINE ROLLER
24	F61-9803	BAIL
25	E46-2101	BAIL TRIP LEVER
26	F12-8901	BAIL SPRING
27	F31-4313	BAIL SPRING COVER
28	E36-4202	BAIL SPRING COVER SCREW
29	F31-4405	BAIL TRIP COVER
30	E46-2001	SPRING HOLDER

Key No.	Parts No.	Parts Name
31	F31-9801	A/R RATCHET
32	L03-6502	BALL BEARING A
33	E52-0101	PINION GEAR
34	F72-7701	BODY
35	E00-7101	A/R PAWL SCREW
36	E46-1302	A/R PAWL
37	E46-1201	A/R PAWL SPRING
38	E03-7801	BEARING RET SCREW
39	F38-5901	A/R CAM SPRING
40	F08-5125	A/R LEVER
41	F13-1601	OSC GEAR COLLAR
42	E46-1501	OSC GEAR
43	631-6901	BALL BEARING B
44	E52-0201	DRIVE GEAR
45	373-7808	DRIVE GEAR WASHER
46	631-6901	BALL BEARING C
47	F72-7801	SIDE COVER
48	B83-5002	SIDE COVER SCREW A
50	B92-4902	HANDLE LOCK SCREW WASHER
51	F03-5605	HANDLE LOCK SCREW
52	F72-7901	HANDLE

### J-Z4000T-3B Special Parts

Key No.	Parts No.	Parts Name
2-9	F72-8201	SPOOL
16	F31-4205	ROTOR
24	F62-0003	BAIL
25	E46-3101	BAIL TRIP LEVER
34	F72-7703	BODY
47	F72-7803	SIDE COVER