


# BAITCASTING REEL MILLIONAIRE-CV-X103A



Key No.	Parts No.	Parts Name
1	G00-2202	L/S OUTER RING
2	G00-1301	BEARING RET A
3	G05-0801	L/S PLT
4	G00-2301	O RING A
5	F79-8001	BRAKE CLICK SPRING
6	G00-2401	BRAKE ADJ KNOB
7	375-7404	SPACER A
8	375-7411	SPACER B
9	F57-4303	SPACER C
10	E08-8003	BALL BEARING A
11	E21-9701	BEARING RET B
12-20	G05-1601	SPOOL
21	G05-0201	FRAME
22	G00-0302	CLUTCH LEVER PLT A
23	G00-0404	CLUTCH LEVER
24	G00-0202	CLUTCH LEVER PLT B
25	F79-3401	CLUTCH CAM RET
26	B86-1702	BALL BEARING B
27	F79-3501	CLUTCH CAM
28	G00-0501	YOKE PLT
29	F79-3801	CLUTCH CAM SCREW
30	F79-4501	CLUTCH SPRING
31	F79-4401	PIN A
32	G00-0601	CLUTCH TRIP PLT
33	F79-4701	CLUTCH TRIP PLT SPRING
34	F79-4601	PIN B
35	371-6905	CLUTCH TRIP PLT WASHER
36	320-1402	CLUTCH TRIP PLT RET
37	F79-4801	YOKE
38	F79-4901	YOKE SPRING
39	F80-1501	PINION GEAR
40	E21-9701	BEARING RET C
41	F64-8301	BUSHING A
42	G05-0003	R/S PLT
43	B67-9304	R/S PLT SCREW
44	F80-0501	PINION SHAFT
45	171-5201	O RING B

Key No.	Parts No.	Parts Name
46	B17-5401	SPOOL ADJ CAP METAL
47	B17-5503	SPACER D
48	F57-4403	CAST CONTROL CAP
49	B86-4101	STABILIZER BAR RET
50	F97-3201	STABILIZER BAR
52	320-5901	WORM SHAFT RET
53	373-1303	WORM SHAFT WASHER
54	F79-5801	WORM SHAFT HOLDER A
55	F79-5101	WORM SHIELD
56	G05-0402	LINE GUIDE
57	F96-6001	LINE GUIDE PAWL
58	375-4101	LINE GUIDE WASHER
59	F40-2803	PAWL CAP
60	F79-5501	WORM SHAFT HOLDER B
61	F84-9102	WORM SHAFT
62	F57-5601	DRIVE SHAFT WASHER
63	B55-0301	BUSHING B
64	G02-2501	DRIVE SHAFT
65	G00-0801	DRIVE SHAFT RET
66	E13-4501	DRIVE SHAFT RET SCREW
67	F76-1701	A/R RATCHET
68	G00-1501	DRIVE GEAR A
69	G00-1601	DRIVE GEAR B
70	F79-6101	EARED WASHER
71	F96-7801	DRAG WASHER
72	F79-6301	KEY WASHER A
73	B36-0303	KEY WASHER B
74	150-8901	DRAG SPRING WASHER
75	G05-3001	GEAR SHAFT COLLAR
76	F99-9801	ROLLER CLUTCH
77	G05-2801	DRAG COLLAR
78	G05-0601	STAR DRAG
79	F85-0401	FRICTION WASHER
80	G05-0701	HANDLE
81	F84-9901	HANDLE NUT
82	F85-0004	HANDLE NUT RET