


SPINNING REEL PR1600H/2000H



Key No. 2-9
E39-1401 Spool assembly

Key No.	Parts No.	Parts Name
1	E37-8801	Drag knob
2	171-7701	Drag washer retainer
3	F01-2001	Key washer
4	E13-6003	Drag washer
5	373-3603	Eared washer
6	E39-1301	Spool assembly
7	B07-5303	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	E39-7901	Spool washer
11	270-6901	Click gear
12	E37-7001	Main shaft
13	B66-2601	Rotor nut holding plate
14	B93-3001	Rotor nut holding plate screw
15	B10-5701	Rotor nut
16	E40-5101	Rotor
17	B67-9305	Line roller screw
18	F00-8501	Bail arm
19	E00-7102	Bail arm screw
20	B55-4301	Line roller washer
21	B45-1501	Line roller bushing
22	E22-5101	Line roller
23	E37-8001	Bail
24	E36-4401	Bail spring shaft
25	E37-7801	Bail spring
26	E37-7901	Bail spring cover
27	E36-4201	Bail spring cover screw
28	F01-1601	Bail trip lever
29	E37-8201	Bail trip cover
30	371-2827	Ball bearing retaining washer
31	B54-6001	Ball bearing A
32	F01-1401	Spacing sleeve
33	E37-6701	Anti-reverse ratchet
34	E37-6601	Pinion gear
35	B88-0001	Pinion holder
36	E37-5501	Body
37	E03-7801	Bearing retainer screw
38	E26-8701	Anti-reverse cam spring

Key No.	Parts No.	Parts Name
39	E37-6001	Anti-reverse lever
40	320-5901	Worm shaft gear retainer
41	E37-6501	Worm shaft gear
42	E39-3501	Worm shaft bush
43	E37-6401	Worm shaft
45	E37-6301	Oscillating slider
46	E19-1201	Oscillating pawl
47	E19-1301	Oscillating pawl bush
48	375-0800	Oscillating pawl washer
49	E37-6901	Oscillating slider cover
50	E40-1501	Oscillating slider cover screw
51	375-4100	Worm shaft washer
52	E36-3801	Worm shaft retainer
53	E39-3601	Worm shaft collar
54	E37-7601	Rear cover
55	E24-8102	Rear cover screw
56	B96-5301	Anti-reverse pawl plate
57	E27-7002	Anti-reverse pawl
58	B96-5501	Anti-reverse pawl collar
59	B96-5601	Anti-reverse pawl spring
60	B00-9701	Anti-reverse pawl screw
61	E37-7201	Anti-reverse pawl spring
62	E37-7101	Drive gear
63	373-7800	Drive gear washer
64	631-6901	Ball bearing B
65	E37-7301	Left side cover
66	E15-8601	Side cover screw A
67	E15-8602	Side cover screw B
68	E38-7101	Handle assembly
69	E12-7501	Handle collar
70	F03-5602	Handle lock screw

PR2000H Special Parts		
2-9	E39-1601	Spool assembly
6	E39-1501	Spool assembly
16	E40-5201	Rotor
23	E38-0201	Bail
36	E37-5503	Body
65	E37-7304	Left side cover
68	E38-9101	Handle assembly