


# SPINNING REEL **RG1355/RG1655**



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	B67-7101	Spool	37	B67-4101	Anti-reverse cam
2	B67-6101	Main shaft	38	144-0321	Anti-reverse cam spring
3	B67-6301	Oscillating slider	39	371-6903	Anti-reverse lever washer
4	B62-0801	Oscillating slider ret. plate	40	541-6801	Anti-reverse lever
5	351-1804	Oscillating slider ret. plate screw	41	353-4401	Anti-reverse lever screw
6	B68-1701	Rotor nut	42	B48-9801	Drag washer holder
7	B67-4401	Rotor	43	B48-9901	Drag washer A
8	B45-1001	Bail kick lever	44	B49-0001	Click gear
9	B68-1301	Bail kick lever cover	45	B49-0101	Drag washer B
10	352-0401	Bail kick lever cover screw	46	B49-0201	Drag washer C
11	363-4411	Bail screw	47	B49-0301	Drag washer D
12	B67-4601	Arm lever	48	B67-8501	Drag washer spring
13	B67-4701	Arm lever screw	49	B67-5601	Drag screw
14	B55-4301	Bail washer	50	B67-5701	Drag washer retainer
15	250-3921	Line roller	51	B67-5801	Drag knob
16	B45-1501	Roller collar	52	352-1105	Drag knob screw
17	B67-5301	Bail	53	B68-2601	Handle screw cap
18	B68-8701	Bail holder screw	54	363-8511	Handle screw
19	B67-4501	Bail spring	55	501-8501	Handle collar
20	B67-4801	Bail spring cover	56	413-4501	Oscillating gear
21	B67-4901	Trigger plate	57	501-6102	Bearing
22	B68-8801	Bail spring cover screw A	58	B67-6001	Drive gear
23	B67-5201	Trigger spring	59	371-2800	Drive gear adjusting washer
24	B67-5101	Trigger lever	60	501-6102	Bearing
25	B68-8801	Trigger screw	61	B67-6401	Body cover
26	B68-6401	Spring holder	62	351-8501	Body cover screw
27	145-0901	Anti-reverse claw spring	63	B67-6901	Handle
28	B67-4301	Ratchet			
29	501-9801	Spacing sleeve			
30	636-6011	Ball bearing			
31	B70-5701	Pinion gear			
32	B67-3601	Body			
33	351-6102	Ball bearing screw			
34	B74-5501	Anti-reverse claw			
36	363-9301	Anti-reverse claw screw			

Special parts for RG1655		
1	B67-8101	Spool
7	B67-8701	Rotor
8	B45-7401	Bail kick lever
17	B69-5601	Bail
32	B67-3602	Body
61	B67-6402	Body cover