



Key No.	Parts No.	Parts Name
2-8	F76-4901	SPOOL
1	F66-2001	DRAG KNOB
2	F71-0001	DRAG WASHER RET
4	F75-6001	DRAG KNOB CLICK PLT
5	F62-7101	DRAG WASHER
6	F75-5701	EARED WASHER
7	F75-5601	KEY WASHER
9	F13-7501	SPOOL WASHER
10	F47-5901	MAIN SHAFT
11	B74-7702	SPOOL CLICK LEAF SPRING
12	B10-5702	ROTOR NUT
13	F18-9601	ROTOR NUT HOLD PLT
14	E13-4501	ROTOR NUT HOLD PLT SCREW
15	F76-3801	ROTOR
16	F14-2004	LINE ROLLER SCREW
17	F45-4301	BAIL ARM
18	F34-5901	BAIL ARM SCREW
19	320-5901	BAIL ARM SCREW RET
20	F70-8101	ROLLER COLLAR
21	F44-6202	LINE ROLLER WASHER
22	F45-4902	LINE ROLLER
23	F84-4901	BALL BEARING A
24	F76-3901	BAIL
25	E12-4701	BAIL SPRING SHAFT
26	E31-3901	BAIL SPRING WASHER
27	E43-5401	BAIL SPRING
28	F35-6905	BAIL SPRING COVER
29	F01-3701	BAIL SPRING COVER SCREW
30	F35-7201	BAIL TRIP PLT
31	F49-9201	BAIL TRIP LEVER
32	F35-7305	BAIL TRIP COVER
33	F19-7304	ROLLER CLUTCH WASHER
34	F76-5401	ROLLER CLUTCH
35	351-4701	ROLLER CLUTCH SCREW
36	F24-6001	SPACING SLEEVE
37	F23-9102	A/R RATCHET
38	F23-8301	BEARING RET
39	F22-6801	A/R PAWL PLT COLLAR
40	F23-8801	A/R PAWL PLT
41	E45-4001	A/R PAWL SCREW
42	F23-8901	A/R PAWL

Key No.	Parts No.	Parts Name
43	F22-7101	A/R CAM SPRING
44	351-8501	BEARING RET SCREW
45	F24-0001	BALL BEARING B
46	371-2822	BALL BEARING WASHER A
47	371-2821	BALL BEARING WASHER B
48	F76-3601	PINION GEAR
49	B88-0001	PINION COLLAR
50	F47-7303	BODY
51	F76-9101	A/R LEVER SPRING
52	E45-0403	A/R LEVER
53	320-5901	WORM SHAFT GEAR RET
54	F76-3501	WORM SHAFT GEAR
55	B45-1501	WORM SHAFT COLLAR
56	E33-2501	BALL BEARING C
57	F76-3401	WORM SHAFT
58	F28-2602	WORM SHIELD
59	E44-6702	OSC SLIDER
60	F02-1202	OSC PAWL
61	E19-1301	OSC PAWL BUSH
62	375-0801	OSC PAWL WASHER
63	E12-5901	OSC SLIDER COVER
64	351-8904	OSC SLIDER COVER SCREW
65	375-4101	OSC SLIDER WASHER
66	F28-2201	BALL BEARING D
67	F28-2301	WORM SHAFT RET
68	F28-2403	BALL BEARING COLLAR B
69	E45-0702	WATER SHIELD
70	E45-0806	REAR COVER
71	F01-6302	REAR COVER SCREW
72	B86-1702	BALL BEARING E
73	F76-3701	DRIVE GEAR
74	373-7808	DRIVE GEAR WASHER
75	B62-8601	BALL BEARING F
76	F08-5004	SIDE COVER
77	351-8505	SIDE COVER SCREW
78	F43-3502	HANDLE COLLAR
79	F76-4801	HANDLE SCREW
80	F76-4001	HANDLE
82	F23-8701	A/R PAWL COLLAR
83	F66-0901	BAIL HOLDER SCREW
84	160-8101	HANDLE WASHER