



KEY #	DESCRIPTION	OFS75
1	DRAG KNOB ASSEMBLY	HT332-01
2	RETAINER, SPOOL, TOP	HT038-01
3	DRAG WASHER, KEYED - SHAFT	HT080-01
4	DRAG FRICTION WASHER	HT030-01
5	DRAG WASHER, KEYED - SPOOL	HT081-01
7	SPOOL SLEEVE	HT160-01
8	SPOOL - ASSEMBLY KIT (includes):	JT4321-01
	2 - RETAINER, SPOOL, TOP	QTY1
	3 - DRAG WASHER, KEYED - SHAFT	QTY2
	4 - DRAG FRICTION WASHER	QTY3
	5 - DRAG WASHER, KEYED - SPOOL	QTY2
	7 - SPOOL SLEEVE	QTY1
	8AA - SPOOL	QTY1
	REAR	QTY1
	8B - DRAG FRICTION WASHER	QTY1
	REAR	QTY1
	8D - BUSHING - CLICKER	QTY1
	8E - SPOOL CLICKER	QTY1
	8F - CLICK SPRING	QTY1
	8G - CLICKER WASHER	QTY1
	8H - SCREW - CLICKER	QTY1
	8J - SCREW - RETAINER - DRAG (REAR)	QTY1
	9 - SPOOL RETAINER - BOTTOM	QTY1
8A	DRAG WASHER, KEYED SPOOL - REAR	HT081-02
8B	DRAG FRICTION WASHER	HT080-02
8C	DRAG, WASHER, KEYED - SHAFT REAR	HT039-01
8D	BUSHING - CLICKER	HT224-01
8E	SPOOL CLICKER	HT103-01
8F	CLICK SPRING	HT068-01
8G	CLICKER WASHER	KT076-01
8H	SCREW - CLICKER	KT085-01
8J	SCREW - RETAINER - DRAG (REAR)	KT228-01
9	SPOOL RETAINER - BOTTOM	HT225-01
10	ROTOR NUT LOCK SCREW	KT111-01
11	ROTOR WASHER	KT065-01
12	ROTOR NUT	KT006-01
13	SCREW - BAIL ARM	KT051-01
13A	BUSHING - BAIL ARM	KT227-01
13B	WASHER - BAIL ARM	KT229-01
14	BAIL ASSEMBLY	HT347-01
15	BUSHING - LINE ROLLER	KT202-01
16	LINE ROLLER	KT004-01

KEY #	DESCRIPTION	OFS75
19	BAIL ARM	KT007-01
20	SCREW - LINE SLIDER	KT106-01
21	SPRING SHAFT	KT031-01
21A	BAIL ARM SPRING	KT044-01
21B	SPRING HOLDER	KT020-01
22	ROTOR COVER	KT087-01
24	SCREW - ROTOR COVER	KT085-01
25	ROTOR	HT009-01
26	CENTER SHAFT ASSY.	KT315-01
27	SCREW AR PAWL	KT111-01
27A	ANTI-REVERSE PAWL RETAINER	KT099-01
28	ANTI - REVERSE PAWL	KT063-01
28A	WASHER, A/R PAWL	HT098-01
29	PINION BEARING	KT028-01
29A	RETAINER PLATE	KT118-01
30	ANTI - REVERSE SPRING SPACER	KT091-01
30A	ANTI - REVERSE ACTUATOR SPRING	KT089-01
30B	SCREW RETAINER PLATE	KT111-01
31	GEAR KIT (includes):	KT4011-01
	31A - PINION	QTY1
	31B - CRANK GEAR ASSEMBLY	QTY1
	31C - D GEAR ADJUST WASHER	QTY1
32	BAIL TRIP	KT019-01
33	SCREW-BAIL TRIP	KT085-01
35	BODY ASSEMBLY	JT301-01
37	O/S GEAR	KT053-01
37A	SPUR GEAR	KT055-01
38	O/S SLIDER	KT025-01
38A	O/S SLIDER RETAINER	KT078-01
39	MAIN SHAFT SCREW	KT111-01
40	BALL BEARING	KT157-01
41	BODY COVER	KT023-01
41A	SEAL CRANK HANDLE	KT139-01
41B	COLLAR - CRANK	KT226-01
42	BODY COVER SCREW KIT (includes):	KT4057-01
	42A - SCREW BODY COVER	QTY4
43	CRANK HANDLE ASSEMBLY	HT318-01
44	BEARING CAP	KT073-01
45	PINION BEARING	KT141-01
46	BEARING RETAINER	KT040-01
47	SCREW RETAINER	KT111-01