


FIN-NOR®

LEGENDARY TACKLE SINCE 1933

Lethal LTC16H



FIN-NOR®

LEGENDARY TACKLE SINCE 1933

Lethal LTC16H

Fin_Nor Lethal Reel

Key No.	Description	Part No.	Qty.	Key No.	Description	Part No.	Qty.
		LTC16H				LTC16H	
1	HANDLE NUT PLATE	SF034-01	1	36	MEDALLION	N/A	0
2	HANDLE NUT	RF003-01	1	37	COVER SCREW	RF057-02	3
3	HANDLE NUT SCREW	RF065-01	1	38	SCREW	N/A	0
4	CRANK HANDLE ASSY	RF318-03	1	39	SPOOL CLICK BUTTON	RF109-01	1
5	SPACER	RF094-01	1	40	CLICK BUTTON WASHER	RF081-01	2
6	DRAG STAR ASSY	RF355-03	1	41	SPOOL CLICK PAWL	RF108-01	1
7	SPOOL TENSION CAP	RF033-02	1	42	RETAINER RING - SPOOL CLICK	RF020-01	1
8	SPACER "A"	RF032-01	1	43-A	BRAKE SLEEVE	RF044-01	2
9	SPACER "B"	RF082-01	1	43-B	BRAKE SLEEVE	RF044-02	2
10	O RING	RF101-01	1	44	SPOOL ASSY	RF321-05	1
11	CLUTCH LEVER ASSY	RF309-02	1	45	DRIVE SHAFT PAD (FELT)	RF155-01	1
12	CLUTCH LEVER COLLAR	RF160-01	1	46	BALL BEARING	SF117-01	1
13	COVER SCREW	RF057-01	3	47	DRIVE SHAFT RETAINER	RF002-51	1
14	RIGHT SIDE COVER ASSY	RF324-07	1	48-A	SCREW	RF107-01	3
15	BUSHING	RF088-02	1	48-B	SCREW	RF107-01	3
16	BUSHING RETAINER	RF080-01	1	49	DRIVE SHAFT	RF008-02	1
17	CLUTCH SPRING	RF104-01	1	50	A/R/ RATCHET	RF091-01	1
18	CLUTCH CAM ASSY	RF384-01	1	51	DRAG WASHER "B"	RF111-01	1
19	RETAINER RING - CLUTCH LEVER	RF092-01	1	52	BALL BEARING	TF117-01	1
20	PINION	RF011-02	1	53	DRIVE GEAR	RF012-02	1
21	YOKE SPRING	RF040-01	2	54	DRAG WASHER "A" (FRICTION)	RF059-03	5
22	YOKE	RF025-01	1	55	KEYED DRAG WASHER	RF045-01	2
23	YOKE PLATE	RF039-01	1	56	TABBED DRAG WASHER	RF048-01	2
24	FRAME ASSEMBLY	RF301-02	1	57	SPRING WASHER	RF046-01	1
25	BALL BEARING	RF058-02	1	58	A/R PAWL ASSY	RF363-01	1
26	CENTRIFUGAL BRAKE RING	RF042-01	1	59	CLUTCH SLEEVE	RF159-01	1
27	SPOOL CLICK SPRING SCREW	RF053-01	1	60	CLUTCH	RF131-01	1
28	SPOOL CLICK SPRING	RF022-01	1	61	HOOD	RF027-03	1
29	BEARING RETAINER	RF129-01	1	62	BALL BEARING	RF058-01	1
30	BEARING WASHER "D" (FELT)	RF122-01	1	63	BEARING WASHER	RF121-01	1
31	BALL BEARING	RF017-01	1	64	SPRING WASHER	RF046-02	2
32	BEARING WASHER "C"	RF035-02	1	65	CLICK SPRING ASSEMBLY	RF314-01	1
33	BEARING WASHER "B"	RF038-01	1	66	BEARING WASHER	RF121-02	1
34	BEARING WASHER "A"	RF035-01	1	67	KIT - ROD CLAMP	RF4154-01	1
35	PALM SIDE COVER ASSY	RF323-02	1	68	WRENCH	RF113-01	1