


# MITCHELL

# AB50



Part No.	Description	Part No.	Description
8429300	BAIL ARM SCREW	8667700	LINE GUIDE WASHER
8429900	ROTATING HEAD HEX NUT	8667800	LINE GUIDE BUSHING
8502000	CROSS WIND BUSHING	8676800	LINE GUIDE RACE
8502700	LINE CLIP	8789800	TRIP LEVER
8502800	RETAINING CLIP	8789900	AXLE
8503300	HANDLE KNOB WASHER	8790100	COUNTERWEIGHT
8503800	LINE GUIDE SCREW	8790300	BAIL LOCK
8503900	HEX NUT LOCKING RING	8790700	BAIL WIRE
8505300	ANTI-REVERSE SHAFT SPRING	8790800	BAIL ARM LEVER
8505500	BALL BEARING	8790900	LEVER SPRING
8505600	SHIM - DRIVE GEAR	8791300	BAIL SCREW
8505900	MOUNTING SCREW	8791400	RACK
8508300	CAP SCREW WASHER	8791700	LEVER SPRING
8508800	HANDLE KNOB SCREW	8791800	BAIL SPRING
8511000	WASHER	8791900	PARTITION PLATE
8513900	BEARING RETAINER	8792100	ANTI-REVERSE DOG
8514000	BRONZE BUSHING	8792400	STOP RACK
8514200	ANTI-REVERSE FRICTION	8792500	COUNTERWEIGHT
8516300	FRICTION SPRING RETAINER	8797200	LINE GUIDE
8549800	HANDLE KNOB	8797300	PINION GEAR
8590700	OSCILLATION SLIDE SCREW	8797700	ANTI-REVERSE SHAFT
8592400	BEARING	8818000	DEEP SPOOL
8592600	SPOOL CLICK	8818100	SHALLOW SPOOL
8593000	EARED DRAG WASHER	8818200	DRAG KNOB
8593100	KEYED DRAG WASHER	8818300	BAIL ARM
8593200	DRAG WASHER	8818400	BAIL MOUNT
8593300	DRAG RETAINER	8818500	COVER PLATE
8593900	BASE DRAG WASHER	8818600	ROTATING HEAD
8595700	SIDE PLATE SCREW	8818700	HANDLE ARM
8596000	RETAINING SCREW	8818800	HANDLE
8597700	BEARING WASHER	8818900	HOUSING
8611300	DRIVE GEAR	8819000	SIDE PLATE
8620200	OSCILLATION SLIDE	8819100	ANTI-REVERSE BUTTON
8620300	CROSS WIND GEAR	8819200	HANDLE CAP SCREW W/WASHER
8620600	SPOOL SPINDLE	8819300	COVER PLATE