


EPIC 10T and 20T



E10T and E20T Parts List			
Item	Description	E10T	E20T
1	Drag Knob	1082569	1071514
2	Spool Assy (Includes Items 80-85)	1084809	1084810
5	Main Shaft	1071116	
7	Bail Wire Assy	1085160	1085161
9	Trigger	1084782	
10	Roller Bearing	1084783	
11	Roller	1071161	
12	Roller Washer (Metal)	1071127	
12A	Roller Washer (Teflon*2)	1084784	
13	Bail Arm	1084785	
14	Roller Screw	1071126	
15	Bail Arm Spring Shaft	1071121	
16	Bail Arm Spring	1071122	
17	Bail Trip Lever	1082573	1071165
18	Bail Arm Cover Screw	1071124	
18A	TRIGGER SCREW	1085090	
20	Bail Arm Cover	1071529	1084786
21	A/R Plate Washer	1084787	
22	Rotor	1084788	1084789
22A	Rotor Guide	1071166	
23	A/R Plate	1084790	
23A	A/R Plate Spring Bushing	1084791	
24	A/R Plate Spring	1084792	
25	Main Body	1084793	1084794
26	Main Body Ball Bearing	1071202	
26A	Side Cover Ball Bearing	1071202	
27	Handle Retrieve Washer	1071192	
28	Handle Nut	1071534	
29	A/R Shaft	1071194	
30	A/R Switch Spring	1071195	
31	A/R Switch	1071535	
32	A/R Switch Screw	1079182	
42	Oscillation Gear	1071197	
44	Slide	1071199	
45	Side Cover Screw	1071204	
47	Pinion Gear Washer	1084795	
48	A/R Control Guide	1084796	
49	Handle Assy	1071517	
50	Main Shaft Washer	1071115	
51	Main Shaft Gear	1071114	
52	Side Cover	1084797	1084798
53	Main Gear Washer	1071201	
54	Main Gear	1071198	
55	Pinion Gear	1071167	
56	Pinion Ball Bearing	1071168	
58	A/R Control Spring	1084801	
59	Ball Bearing Screw	1084803	
60	Bail Arm / Weight Screw	1071162	
61	Bail Wire Weight Cover	1071531	1084808
63	Hex Nut	1071119	
63A	Retained Plate Screw	1071117	
63B	Retained Plate	1071118	
66	Slide Screw	1071200	
67	A/R Plate Screw	1084806	
69	Rear Cover	1071532	
70	Rear Cover Screw	1079183	
80	Spool Retaining Ring	1071108	
81	Drag Washer (metal)	1071109	
82	Drag Washer (ear)	1071110	
83	Front Drag Washer	1071111	
84	Drag Washer (2)	1071112	
85	Back Drag Washer	1071113	

57