



Part No.	Description	Part No.	Description
8319000	OIL DUST SHIELD	8673600	OSCILLATION SLIDE SCREW
8321100	SHIM - DRIVE GEAR	8674200	BEARING
8429300	BAIL ARM SCREW	8674300	KEYED WASHER
8460400	SIDE PLATE SCREW	8674400	DRAG HEX NUT
8502700	LINE CLIP	8674500	DRAG SPRING
8502800	RETAINING CLIP	8674600	DRAG WASHER
8505300	ANTI-REVERSE SHAFT SPRING	8674700	BASE DRAG WASHER
8505400	RETAINER SCREW	8674900	SPOOL CLICK
8505900	MOUNTING SCREW	8675000	SPOOL CLICK SPRING
8507100	DRAG CLICK	8675100	BUTTON & CLICK SCREW
8507200	DRAG CLICK SPRING	8675200	BAIL WIRE W/COVER PLATE
8508300	CAP SCREW WASHER	8676000	HEX NUT
8651600	BAIL SPRING PIN	8676100	LINE GUIDE SCREW
8666700	LINE GUIDE	8676200	HEX NUT RETAINER
8667700	LINE GUIDE WASHER	8676400	BEARING WASHER
8667800	LINE GUIDE BUSHING	8676800	LINE GUIDE RACE
8670300	DRIVE GEAR	8680200	RETAINER SCREW
8670400	PINION GEAR	8683000	CROSS WIND GEAR
8670600	OSCILLATION SLIDE	8815200	ANTI-REVERSE BUTTON
8670700	BEARING RETAINER	8815300	DRAG KNOB
8671000	ANTI-REVERSE SHAFT	8815400	DRAG ASSEMBLY
8671500	TRIP LEVER	8815500	SPOOL
8671600	AXLE W/CLICK GEAR	8815600	BAIL ARM
8671700	BAIL SPRING	8815700	ROTATING HEAD
8672000	ANTI-REVERSE FRICTION	8815800	COVER PLATE
8672100	DRIVE GEAR BUSHING	8815900	HANDLE CAP SCREW W/WASHER
8672200	ANTI-REVERSE DOG	8816000	HOUSING
8673100	ANTI-REVERSE BUSHING	8816100	SIDE PLATE
8673200	ROTATING HEAD WASHER	8816200	HANDLE
8673500	CLICK GEAR		