



DESCRIPTION	SC400P			
1 SIDE PLATE (NON-GEAR)	1065982	21 BALL BEARING	1066027	43 SIDE PLATE (G)
2 FRAME	1066008	22 RETAINER	1066028	44 GEAR PLATE
3 CARRIER GUIDE	1066010	23 BREAK SHOE	1066030	45 O-RING
4 E-CLIP	1066011	24 SPOOL	1066031	46 BUSHING
5 WORM SHAFT BUSHING	1066012	25 RETAINER	1066028	47 TENSION SHIM
6 WORM SHAFT COVER	1066013	26 BALL BEARING	1066033	49 TENSION RUE
7 CARRIER	1066014	27 E-CLIP	1066034	50 TENSION KNC
8 PAWL	1065910	28 BUSHING	1066035	51 CRANK SHAF
9 PAWL ADJUSTMENT SHIM	1065915	29 GEAR PLATE	1066036	52 CRANK SHAF
10 PAWL CAP	1065909	30 SPRING BUSHING	1066038	53 O/S GEAR
11 WORM SHAFT	1066015	31 KICKER PLATE	1066039	54 LATCH GEAR
12 WORM GEAR BUSHING	1066017	32 KICKER PLATE SPRING	1066041	55 SPACER WAS
13 WORM SHAFT GEAR	1065914	33 THUMB BAR PLATE	1066043	56 DRIVE GEAR
14 E-CLIP	1066018	34 E-CLIP	1066045	57 DRAG B WASI
15 THUMB BAR GUIDE	1066019	35 E-CLIP	1066046	58 DRAG D WASI
16 THUMB BAR	1066021	36 THUMB BAR SPRING	1066047	59 SLEEVE
17 WASHER	1066023	37 PINION	1066049	60 CLUTCH BEA
18 E-CLIP	1066018	38 PINION YOKE	1066051	61 WASHER
19 SIDE PLATE SCREWS	1066025	39 YOKE SPRINGS	1066053	62 DRAG SPRING
20 SPOOL WASHER	1066026	40 O-RINGS	1066054	63 WASHER
		42 SIDE PLATE SCREWS	1066055	64 STAR DRAG