



DESCRIPTION	SCL300	
1 FRAME ASSEMBLY	1071417	22 LATCH SCREW WASHER
2 LOCKER SPRING	8889430	23 LATCH
3 LOCKER	8889431	24 PINION YOKE
4 CARRIER GUIDE	8889432	25 YOKE SPRING
5 CARRIER GUIDE S/C WASHER	8889433	26 PINION GEAR
6 CARRIER GUIDE SCREW	8889434	27 BEARING PLATE
7 E-CLIP	8889435	28 BEARING PLATE SCREW
8 CARRIER	1071418	29 BEARING PLATE SCREW
9 PAWL	8889437	30 BUSHING
10 PAWL CAP WASHER	8889438	31 CRANK SHAFT
11 PAWL CAP	8889587	32 C/S GEAR
12 WORM SHAFT	8889440	33 LATCH GEAR
13 WORM SHAFT BUSHING	8889441	34 SPACER WASHER
14 O/S PINION	8889442	35 DRIVE GEAR
15 E-CLIP	8889443	36 DRAG "B" WASHER
16 THUMB BAR	8889444	37 DRAG "D" WASHER
17 KICKER	8889445	38 RIGHT SIDE COVER
18 KICKER SPRING	8889446	39 RIGHT SIDE COVER SCR
19 FLIPPIN LEVER	8889447	40 BUSHING
20 FLIPPIN LEVER S/P	8889448	41 TENSION SPRING
21 LATCH SCREW	8889449	42 TENSION SHIM
		43 TENSION RUBBER