



| | | | | | | |
|----------------------|----|---------|-----------------|----|---------|--------------------|
| CLUTCH SCREW | 43 | 8889474 | TENSION SPRING | 63 | 8889489 | PLATE SPRING |
| CLUTCH SCREW | 44 | 8889475 | TENSION SHIM | 64 | 8889581 | SPOOL |
| CLUTCH | 45 | 8889476 | TENSION RUBBER | * | 8889595 | SPOOL |
| CLUTCH YOKE | 46 | 8889477 | TENSION KNOB | 65 | 8889494 | ARBOR ASSY |
| CLUTCH YOKE SPRING | * | 8889592 | TENSION KNOB | 66 | 8889495 | ARBOR SPRING |
| CLUTCH GEAR | 47 | 8889478 | CLUTCH BEARING | 67 | 8889497 | BRAKE HOUSING |
| CLUTCH BEARING PLATE | 48 | 8889479 | SLEEVE | 68 | 8889496 | BRAKE SHOE |
| CLUTCH SCREW | 49 | 8889481 | WAVE WASHER | 69 | 8889494 | ARBOR ASSY |
| CLUTCH SCREW | 50 | 8889482 | DRAG NUT | 70 | 8889499 | SPOOL COVER |
| CLUTCH BEARING | 51 | 8889571 | DRAG SPRING | 71 | 8889582 | SCREW |
| CLUTCH SHIM | 52 | 8889572 | STAR DRAG | 72 | 8889501 | SPOOL COVER SCREW |
| CLUTCH SHAFT | 53 | 8889573 | CLAW | 73 | 8889502 | BALL BEARING |
| CLUTCH GEAR | 54 | 8889574 | CLAW SPRING | 74 | 8889503 | RING |
| CLUTCH GEAR | 55 | 8889575 | HANDLE ASSY | 75 | 8889504 | SPOOL COVER WASHER |
| CLUTCH WASHER | * | 8889593 | HANDLE ASSY | 76 | 8889583 | LEFT SIDE COVER |
| CLUTCH GEAR | 56 | 8889576 | HANDLE KNOB CAP | 77 | 8889508 | KEY |
| CLUTCH "B" WASHER | * | 8889594 | HANDLE KNOB CAP | 78 | 8889507 | SCREW |
| CLUTCH "D" WASHER | 57 | 8889577 | HANDLE NUT | 79 | 8889584 | LEFT PAD |
| CLUTCH SIDE COVER | 58 | 8889578 | HANDLE NUT CAP | 80 | 8889585 | METAL INSERT PLATE |
| CLUTCH SCREW | 59 | 8889579 | SCREW | * | 8889586 | METAL INSERT PLATE |
| CLUTCH SCREW | 60 | 8889491 | SPOOL CAP | 81 | 8889508 | BUTTON SPRING |
| CLUTCH BEARING | 61 | 8889492 | SPOOL CAP SCREW | 82 | 8889586 | BUTTON |
| CLUTCH SHIM | 62 | 8889490 | PLATE | | | |

* SCP300L only