



SCS10

|             |    |          |                          |
|-------------|----|----------|--------------------------|
| ick)        | 52 | 888-9987 | Side Cover Assembly      |
| ocker       | 53 | 859-5700 | Side Cover Screw (Black) |
| on Spring   | 54 | 888-9988 | Anti-Reverse Switch      |
| ght         | 55 | 883-0200 | Anti-Reverse Shaft       |
|             | 56 | 850-5300 | Anti-Reverse Spring      |
| er Plate    | 57 | 888-9989 | Body Assembly            |
| g           | 58 | 883-1900 | Fixed Oscillation Gear   |
| se Sleeve   | 59 | 883-2500 | Driver Oscillation Gear  |
| ve          | 60 | 883-2600 | Oscillation Gear         |
|             | 61 | 859-0700 | Oscillation Shaft Screw  |
|             | 62 | 883-0500 | Oscillation Slide        |
| Bearing     | 63 | 882-9100 | Oscillation Slide Bar    |
| ng Retainer | 64 | 888-9991 | AVR Pawl Assembly        |
| alner Screw | 65 | 880-5200 | Brass Sleeve             |
| Assembly    | 66 | 8896004  | Drive Bearing Retainer   |
| Washer      | 67 | 888-9992 | Crank Handle Assembly    |